


Turbocharger cooling for vehicles with 4 wheel drive

30
15
X
31

ge = yellow
ws = white
ro = red
li = lilac
bl = blue
gr = grey
gn = green
br = brown
sw = black



F 95 — Thermoswitch for coolant circulation run on
J 151 — Relay for coolant circulation in engine compartment left
J 183 — Cooling blower relay, in engine compartment, left
S 51 — Fuse, in engine compartment junction box
T 1 — Connector single, in engine compartment, left
V 62 — Turbocharger cooling blower, in engine compartment, left

(P1) — Positive (+) connection (30) in junction box – engine compartment

(12) — Earth point, in engine compartment, left