



F RELAY LOCATIONS


[Engine Compartment]



[Body]



[Instrument Panel]




cardiagn.com

F RELAY LOCATIONS


② : Engine Room R/B

Engine Compartment Left (See Page 20)


- *1:ACC CUT Relay
- *2:FR FOG Relay
- *3:STA Relay
- *4:HEATER Relay
- *5:MG CLT Relay
- *6:ABS SOL Relay
- *7:C/OPN Relay
- *8:DOME Relay
- *9:EFI Relay
- *10:A/F HEATER Relay
- *11:HEAD (LO LH)
- *12:HEAD (HI LH)
- *13:RADIO NO.1



③ : Engine Room R/B No.3	Engine Compartment Left (See Page 20)
--------------------------	---------------------------------------




④ : Engine Room R/B No.4	Engine Compartment Left (See Page 20)
--------------------------	---------------------------------------



 : Driver Side J/B


2004 4RUNNER (EWD552U)






F RELAY LOCATIONS

[Driver Side J/B Inner Circuit]




(Cont. Next Page)



F RELAY LOCATIONS

○ : Center J/B


Instrument Panel Brace RH (See Page 21)



cardiagn.com

F RELAY LOCATIONS

[Center J/B Inner Circuit]



(Cont. Next Page)

(Cont'd)

F (3E)	
F (3E)	
F (3E)	
E (3E)	
E (3E)	
E (3E)	
D (3E)	
D (3E)	
D (3E)	
C (3E)	
C (3E)	
C (3E)	
A (3F)	
A (3F)	
A (3F)	
A (3F)	
A (3F)	
A (3F)	
A (3F)	
A (3F)	
A (3F)	
B (3F)	
B (3F)	
B (3F)	
B (3F)	
B (3F)	
B (3F)	
B (3F)	
B (3F)	
B (3F)	
B (3F)	
B (3F)	