






- A 1 Headlight Assembly RH
- A 2 Headlight Assembly LH
- A 5 Headlight Assembly RH
- A 6 Headlight Assembly LH
- A 7 Headlight Assembly RH
- A 8 Headlight Assembly LH
- A 9 Fog Light Assembly RH
- A 10 Fog Light Assembly LH
- A 11 Headlight Assembly RH
- A 12 Headlight Assembly LH
- A 13 Low Pitched Horn Assembly
- A 15 Windshield Wiper Motor Assembly
- A 16 Windshield Washer Motor and Pump Assembly
- A 17 Rear Washer Motor and Pump Assembly
- A 18 Front Speed Sensor RH
- A 19 Front Speed Sensor LH
- A 20 Front Airbag Sensor

cardiagn.com










cardiagn.com

- * 1:w/ VSC
- * 2:w/o VSC




- A 21 Cooling Fan Motor
- A 22 Cooling Fan Resistor
- A 23 A/C Pressure Sensor (Liquid Tube Sub-Assembly)
- A 24 Ambient Temperature Sensor (Thermistor Assembly)
- A 25 Brake Fluid Level Warning Switch (Brake Master Cylinder Reservoir Sub-Assembly)
- A 27 Fuel Sedimenter Level Warning Switch
- A 28 Intake Mass Air Flow Meter Sub-Assembly
- A 29 Heater Assembly
- A 30 Fuel Pump Sub-Assembly
- A 31 Battery Current Sensor Assembly
- A 34 Wireless Door Lock Buzzer
- A 49 Select Stroke Sensor
- A 54 Skid Control ECU with Actuator Assembly
- A 55 Skid Control ECU with Actuator Assembly
- A 59 ECM
- A 65 Fusible Link Block Assembly
- A 66 Fusible Link Block Assembly
- A 74 Headlight Assembly RH
- A 75 Headlight Assembly LH


cardiagn.com



cardiagn.com













cardiagn.com




- B 1 Starter Assembly
- B 2 Generator Regulator Assembly
- B 3 Generator Regulator Assembly
- B 6 Injector Assembly No. 1
- B 8 Injector Assembly No. 2
- B 10 Injector Assembly No. 3
- B 12 Injector Assembly No. 4
- B 21 ECM
- B 26 Crankshaft Position Sensor
- B 27 Engine Oil Level Sensor
- B 28 Oil Pressure Sensor
- B 30 Camshaft Position Sensor
- B 34 Fuel Pressure Sensor
- B 36 Turbocharger Sub-Assembly
- B 38 Air Fuel Ratio Sensor (Bank 1 Sensor 1)
- B 40 Exhaust Gas Temperature Sensor

cardiagn.com



cardiagn.com




















- B 41 No. 2 Exhaust Gas Temperature Sensor
- B 42 Intake Air Temperature Sensor
- B 43 Differential Pressure Sensor
- B 44 Fuel Temperature Sensor
- B 49 Diesel Turbo Pressure Sensor
- B 50 Clutch Stroke Sensor
- B 51 Transmission Revolution Sensor
- B 54 Turbocharger Sub-Assembly
- B 55 Electric EGR Control Valve Assembly
- B 58 Shift and Select Actuator Assembly
- B 59 Shift and Select Actuator Assembly
- B 60 Clutch Actuator Assembly
- B 62 No. 2 EGR Valve Assembly
- B 65 Oil Pressure Switching Valve Assembly
- B 66 VSV (Pressure Release Valve)
- B 67 Injection or Supply Pump Assembly
- B 71 Back-Up Light Switch Assembly
- B 75 Glow Plug Assembly
- B 76 Glow Plug Relay Assembly
- B 77 With Pulley Compressor Assembly
- B 78 Fusible Link Block Assembly
- B 79 Fusible Link Block Assembly
- B 80 Diesel Engine Coolant Temperature Sensor
- B 81 Diesel Throttle Body Assembly


- C 1 Starter Assembly


- E 2 Park/Neutral Position Switch Assembly
- E 3 Shift Stroke Sensor

cardiagn.com




cardiagn.com






cardiagn.com




- A 1 Headlight Assembly RH
- A 2 Headlight Assembly LH
- A 5 Headlight Assembly RH
- A 6 Headlight Assembly LH
- A 7 Headlight Assembly RH
- A 8 Headlight Assembly LH
- A 9 Fog Light Assembly RH
- A 10 Fog Light Assembly LH
- A 11 Headlight Assembly RH
- A 12 Headlight Assembly LH
- A 13 Low Pitched Horn Assembly
- A 15 Windshield Wiper Motor Assembly
- A 16 Windshield Washer Motor and Pump Assembly
- A 17 Rear Washer Motor and Pump Assembly
- A 18 Front Speed Sensor RH
- A 19 Front Speed Sensor LH
- A 20 Front Airbag Sensor

cardiagn.com













cardiagn.com




- A 21 Cooling Fan Motor
- A 22 Cooling Fan Resistor
- A 23 A/C Pressure Sensor (Liquid Tube Sub-Assembly)
- A 24 Ambient Temperature Sensor (Thermistor Assembly)
- A 25 Brake Fluid Level Warning Switch (Brake Master Cylinder Reservoir Sub-Assembly)
- A 31 Battery Current Sensor Assembly
- A 32 Engine Hood Courtesy Switch Assembly (Hood Lock Assembly)
- A 33 Brake Booster Pressure Sensor (Vacuum Sensor Assembly)
- A 34 Wireless Door Lock Buzzer
- A 35 ECO Run Vehicle Converter Assembly
- A 54 Skid Control ECU with Actuator Assembly
- A 55 Skid Control ECU with Actuator Assembly
- A 56 Skid Control ECU with Actuator Assembly
- A 57 Skid Control ECU with Actuator Assembly
- A 58 ECM
- A 65 Fusible Link Block Assembly
- A 66 Fusible Link Block Assembly
- A 74 Headlight Assembly RH
- A 75 Headlight Assembly LH

cardiagn.com




cardiagn.com


A 56
Black




A 57
Black



A 58
Black




A 65
Black



cardiagn.com

A 66
White




A 74
Gray



















A 75
Gray






- B 1 Starter Assembly
- B 2 Generator Regulator Assembly
- B 3 Generator Regulator Assembly
- B 5 Fuel Injector Assembly No. 1
- B 7 Fuel Injector Assembly No. 2
- B 9 Fuel Injector Assembly No. 3
- B 11 Fuel Injector Assembly No. 4
- B 14 Ignition Coil Assembly No. 1
- B 16 Ignition Coil Assembly No. 2
- B 18 Ignition Coil Assembly No. 3
- B 20 Ignition Coil Assembly No. 4
- B 22 ECM
- B 24 Crankshaft Position Sensor
- B 29 Throttle with Motor Body Assembly
- B 31 VVT Sensor (Bank 1 Exhaust Side)
- B 32 VVT Sensor (Bank 1 Intake Side)
- B 33 E.F.I. Engine Coolant Temperature Sensor
- B 35 E.F.I. Vacuum Sensor Assembly
- B 37 Oxygen Sensor (Bank 1 Sensor 2)
- B 39 Air Fuel Ratio Sensor (Bank 1 Sensor 1)

cardiagn.com



















cardiagn.com




- B 45 Oil Pressure Sensor
- B 46 Transmission Revolution Sensor (Primary)
- B 47 Transmission Revolution Sensor (Secondary)
- B 48 Transmission Revolution Sensor (Turbine)
- B 53 Starter Assembly
- B 56 EGR Valve Assembly
- B 57 Oil Pump Motor Assembly
- B 61 Purge VSV
- B 63 Camshaft Timing Oil Control Valve Assembly (Bank 1 Intake Side)
- B 64 Camshaft Timing Oil Control Valve Assembly (Bank 1 Exhaust Side)
- B 68 Engine Oil Pressure Switch Assembly
- B 69 Park/Neutral Position Switch Assembly
- B 70 Park/Neutral Position Switch Assembly
- B 71 Back-Up Light Switch Assembly
- B 73 Intake Mass Air Flow Meter Sub-Assembly
- B 74 CVT Solenoid
- B 77 With Pulley Compressor Assembly
- B 78 Fusible Link Block Assembly


- E 1 Knock Control Sensor (Bank 1)

cardiagn.com




cardiagn.com






cardiagn.com




- A 1 Headlight Assembly RH
- A 2 Headlight Assembly LH
- A 5 Headlight Assembly RH
- A 6 Headlight Assembly LH
- A 7 Headlight Assembly RH
- A 8 Headlight Assembly LH
- A 9 Fog Light Assembly RH
- A 10 Fog Light Assembly LH
- A 11 Headlight Assembly RH
- A 12 Headlight Assembly LH
- A 13 Low Pitched Horn Assembly
- A 14 Security Horn Assembly
- A 15 Windshield Wiper Motor Assembly
- A 16 Windshield Washer Motor and Pump Assembly
- A 17 Rear Washer Motor and Pump Assembly
- A 18 Front Speed Sensor RH
- A 19 Front Speed Sensor LH
- A 20 Front Airbag Sensor

cardiagn.com











cardiagn.com




- A 21 Cooling Fan Motor
- A 22 Cooling Fan Resistor
- A 23 A/C Pressure Sensor (Liquid Tube Sub-Assembly)
- A 24 Ambient Temperature Sensor (Thermistor Assembly)
- A 25 Brake Fluid Level Warning Switch (Brake Master Cylinder Reservoir Sub-Assembly)
- A 31 Battery Current Sensor Assembly
- A 32 Engine Hood Courtesy Switch Assembly (Hood Lock Assembly)
- A 34 Wireless Door Lock Buzzer
- A 54 Skid Control ECU with Actuator Assembly
- A 58 ECM
- A 65 Fusible Link Block Assembly
- A 66 Fusible Link Block Assembly
- A 74 Headlight Assembly RH
- A 75 Headlight Assembly LH

cardiagn.com




cardiagn.com




- B 1 Starter Assembly
- B 2 Generator Regulator Assembly
- B 3 Generator Regulator Assembly
- B 5 Fuel Injector Assembly No. 1
- B 7 Fuel Injector Assembly No. 2
- B 9 Fuel Injector Assembly No. 3
- B 11 Fuel Injector Assembly No. 4
- B 14 Ignition Coil Assembly No. 1
- B 16 Ignition Coil Assembly No. 2
- B 18 Ignition Coil Assembly No. 3
- B 20 Ignition Coil Assembly No. 4
- B 23 ECM
- B 24 Crankshaft Position Sensor
- B 29 Throttle with Motor Body Assembly
- B 31 VVT Sensor (Bank 1 Exhaust Side)
- B 32 VVT Sensor (Bank 1 Intake Side)
- B 33 E.F.I. Engine Coolant Temperature Sensor
- B 35 E.F.I. Vacuum Sensor Assembly
- B 37 Oxygen Sensor (Bank 1 Sensor 2)
- B 39 Air Fuel Ratio Sensor (Bank 1 Sensor 1)

cardiagn.com




cardiagn.com





- B 45 Oil Pressure Sensor
- B 46 Transmission Revolution Sensor (Primary)
- B 47 Transmission Revolution Sensor (Secondary)
- B 48 Transmission Revolution Sensor (Turbine)
- B 53 Starter Assembly
- B 56 EGR Valve Assembly
- B 61 Purge VSV
- B 63 Camshaft Timing Oil Control Valve Assembly (Bank 1 Intake Side)
- B 64 Camshaft Timing Oil Control Valve Assembly (Bank 1 Exhaust Side)
- B 68 Engine Oil Pressure Switch Assembly
- B 69 Park/Neutral Position Switch Assembly
- B 71 Back-Up Light Switch Assembly
- B 73 Intake Mass Air Flow Meter Sub-Assembly
- B 74 CVT Solenoid
- B 77 With Pulley Compressor Assembly
- B 78 Fusible Link Block Assembly


- E 1 Knock Control Sensor (Bank 1)



cardiagn.com




















- A 1 Headlight Assembly RH
- A 2 Headlight Assembly LH
- A 3 Headlight Assembly RH
- A 4 Headlight Assembly LH
- A 5 Headlight Assembly RH
- A 6 Headlight Assembly LH
- A 7 Headlight Assembly RH
- A 8 Headlight Assembly LH
- A 9 Fog Light Assembly RH
- A 10 Fog Light Assembly LH
- A 11 Headlight Assembly RH
- A 12 Headlight Assembly LH
- A 13 Low Pitched Horn Assembly
- A 15 Windshield Wiper Motor Assembly
- A 16 Windshield Washer Motor and Pump Assembly
- A 17 Rear Washer Motor and Pump Assembly
- A 18 Front Speed Sensor RH
- A 19 Front Speed Sensor LH
- A 20 Front Airbag Sensor

cardiagn.com










cardiagn.com

- * 1: Hong Kong Before Nov. 2011 Production
- * 5: w/ VSC
- * 6: w/o VSC
- * 10: Before Sep. 2013 Production
- * 11: From Sep. 2013 Production




- A 21 Cooling Fan Motor
- A 22 Cooling Fan Resistor
- A 23 A/C Pressure Sensor (Liquid Tube Sub-Assembly)
- A 24 Ambient Temperature Sensor (Thermistor Assembly)
- A 25 Brake Fluid Level Warning Switch (Brake Master Cylinder Reservoir Sub-Assembly)
- A 31 Battery Current Sensor Assembly
- A 32 Engine Hood Courtesy Switch Assembly (Hood Lock Assembly)
- A 33 Brake Booster Pressure Sensor (Vacuum Sensor Assembly)
- A 34 Wireless Door Lock Buzzer
- A 54 Skid Control ECU with Actuator Assembly
- A 55 Skid Control ECU with Actuator Assembly
- A 58 ECM
- A 60 Fuel Pump Control ECU Assembly
- A 65 Fusible Link Block Assembly
- A 66 Fusible Link Block Assembly
- A 67 Option Connector (Fog Light Assembly RH)
- A 68 Option Connector (Fog Light Assembly LH)
- A 74 Headlight Assembly RH
- A 75 Headlight Assembly LH
- A 77 Headlight Assembly RH
- A 78 Headlight Assembly LH

cardiagn.com




cardiagn.com


A 58
Black




A 60
Black




A 65
Black




A 66
White



A 67
Black



A 68
Black




A 74
Gray




A 75
Gray



A 77
Black




A 78
Black







cardiagn.com


* 3: Before Aug. 2012 Production
 * 7: w/o Stop & Start System
 Before Aug. 2012 Production



- B 1 Starter Assembly
- B 2 Generator Regulator Assembly
- B 4 Generator Regulator Assembly
- B 5 Fuel Injector Assembly No. 1
- B 7 Fuel Injector Assembly No. 2
- B 9 Fuel Injector Assembly No. 3
- B 11 Fuel Injector Assembly No. 4
- B 13 Ignition Coil Assembly No. 1
- B 15 Ignition Coil Assembly No. 2
- B 17 Ignition Coil Assembly No. 3
- B 19 Ignition Coil Assembly No. 4
- B 23 ECM
- B 25 Crankshaft Position Sensor
- B 29 Throttle with Motor Body Assembly
- B 30 Camshaft Position Sensor
- B 33 E.F.I. Engine Coolant Temperature Sensor
- B 39 Air Fuel Ratio Sensor (Bank 1 Sensor 1)
























cardiagn.com




- B 45 Oil Pressure Sensor
- B 46 Transmission Revolution Sensor (Primary)
- B 47 Transmission Revolution Sensor (Secondary)
- B 48 Transmission Revolution Sensor (Turbine)
- B 52 E.G.R. Gas Temperature Sensor
- B 53 Starter Assembly
- B 56 EGR Valve Assembly
- B 61 Purge VSV
- B 63 Camshaft Timing Oil Control Valve Assembly (Bank 1 Intake Side)
- B 68 Engine Oil Pressure Switch Assembly
- B 69 Park/Neutral Position Switch Assembly
- B 72 Intake Mass Air Flow Meter Sub-Assembly
- B 74 CVT Solenoid
- B 77 With Pulley Compressor Assembly
- B 78 Fusible Link Block Assembly
- B 82 Fuel Injector Assembly No. 1
- B 83 Crankshaft Position Sensor
- B 84 Cam Position Sensor
- B 85 E.F.I. Vacuum Sensor Assembly
- B 86 CVT Solenoid
- B 87 Starter Assembly
- B 88 Crankshaft Position Sensor
- B 89 Oil Pump Motor Assembly
- B 90 Park/Neutral Position Switch Assembly


- R 1 Knock Control Sensor (Bank 1)





cardiagn.com


- * 1:Before Aug. 2012 Production
- * 2:From Aug. 2012 Production




























G 2 Power Window Regulator Switch Assembly
G 4 Front Power Window Regulator Motor Assembly RH
G 5 Front Door with Motor Lock Assembly RH
G 6 Outer Rear View Mirror Assembly RH
G 7 Outer Rear View Mirror Assembly RH
G 8 Front No. 1 Speaker Assembly RH
G 9 Front No. 2 Speaker Assembly RH
G 11 Electrical Key Antenna RH
G 12 Short Connector (Front No. 2 Speaker Assembly RH)

H 1 Power Window Regulator Master Switch Assembly
H 3 Front Power Window Regulator Motor Assembly LH
H 5 Front Door with Motor Lock Assembly LH
H 6 Outer Rear View Mirror Assembly LH
H 7 Outer Rear View Mirror Assembly LH
H 8 Front No. 1 Speaker Assembly LH
H 9 Front No. 2 Speaker Assembly LH
H 11 Electrical Key Antenna LH
H 12 Short Connector (Front No. 2 Speaker Assembly LH)







I 1 Rear Power Window Regulator Switch Assembly RH
I 2 Rear Power Window Regulator Motor Assembly RH
I 3 Rear Door with Motor Lock Assembly RH
I 4 Rear Speaker Assembly RH

J 1 Rear Power Window Regulator Switch Assembly LH
J 2 Rear Power Window Regulator Motor Assembly LH
J 3 Rear Door with Motor Lock Assembly LH
J 4 Rear Speaker Assembly LH


cardiagn.com



cardiagn.com












* 3:w/ Entry & Start System
 * 4:w/o Entry & Start System




- K 1 Front Door Courtesy Light Switch Assembly LH
- K 2 Front Door Courtesy Light Switch Assembly RH
- K 3 Rear Door Courtesy Light Switch Assembly LH
- K 4 Rear Door Courtesy Light Switch Assembly RH
- K 5 Rear Combination Light LH
- K 6 Rear Combination Light RH
- K 7 No. 2 Room Light Assembly
- K 8 Front Seat Inner Belt Assembly LH
- K 9 Front Seat Inner Belt Assembly RH
- K 10 Door Control Receiver
- K 11 No. 2 Indoor Electrical Key Antenna Assembly
- K 12 Door Control Receiver
- K 13 Rear Indoor Electrical Key Antenna
- K 14 Rear Seat Inner with Center Belt Assembly LH (Rear Seat LH)
- K 15 Rear Seat Inner Belt Assembly RH

cardiagn.com



















cardiagn.com

* 7:w/ Curtain Shield Airbag
 * 8:w/o Curtain Shield Airbag




- K 16 Rear Seat Inner with Center Belt Assembly LH (Rear Seat Center)
- K 17 Fuel Sender Gage Assembly
- K 20 Rear Power Point Socket Assembly
- K 21 Side Airbag Sensor Assembly LH
- K 22 Side Airbag Sensor Assembly RH
- K 23 No. 2 Side Airbag Sensor Assembly LH
- K 24 No. 2 Side Airbag Sensor Assembly RH
- K 25 Front Seat Outer Belt Assembly LH
- K 26 Front Seat Outer Belt Assembly RH
- K 27 Curtain Shield Airbag Assembly LH
- K 28 Curtain Shield Airbag Assembly RH
- K 29 Front Seat Airbag Assembly LH
- K 30 Front Seat Airbag Assembly RH
- K 35 Side Airbag Sensor Assembly LH
- K 36 Side Airbag Sensor Assembly RH
- K 37 Tire Pressure Warning ECU and Receiver

cardiagn.com



cardiagn.com

* 5:w/ Roof Sunshade System
 * 6:w/o Roof Sunshade System



- L 1 Map Light Assembly
- L 2 Map Light Assembly
- L 3 No. 1 Room Light Assembly
- L 4 Inner Rear View Mirror Assembly
- L 5 Rain Sensor
- L 7 Slide Roof Motor Switch
- L 8 Amplifier Microphone Assembly

- M 2 Rear Light Assembly RH
- M 3 Rear Light Assembly LH

- O 1 Center Stop Light Assembly

- P 2 Rear Wiper Motor Assembly
- P 3 Rear Television Camera Assembly
- P 4 License Plate Light Assembly RH
- P 5 License Plate Light Assembly LH
- P 6 Rear Window Defogger (Back Door Glass)
- P 7 Back Door Lock Assembly
- P 8 Back Door Opener Switch Assembly


- Q 1 Rear Window Defogger (Back Door Glass)

- V 1 Rear Speed Sensor LH


- W 1 Rear Speed Sensor RH

- a 1 Sliding Roof Drive Gear Assembly


cardiagn.com




cardiagn.com




JK1
White




JK1
White




La1
White




MK1
White




OK1
White




OP1
White




cardiagn.com



cardiagn.com






















G 1 Power Window Regulator Master Switch Assembly
 G 3 Front Power Window Regulator Motor Assembly RH
 G 5 Front Door with Motor Lock Assembly RH
 G 6 Outer Rear View Mirror Assembly RH
 G 7 Outer Rear View Mirror Assembly RH
 G 8 Front No. 1 Speaker Assembly RH
 G 9 Front No. 2 Speaker Assembly RH
 G 10 Electrical Key Antenna RH
 G 12 Short Connector (Front No. 2 Speaker Assembly RH)

H 2 Power Window Regulator Switch Assembly
 H 4 Front Power Window Regulator Motor Assembly LH
 H 5 Front Door with Motor Lock Assembly LH
 H 6 Outer Rear View Mirror Assembly LH
 H 7 Outer Rear View Mirror Assembly LH
 H 8 Front No. 1 Speaker Assembly LH
 H 9 Front No. 2 Speaker Assembly LH
 H 10 Electrical Key Antenna LH
 H 12 Short Connector (Front No. 2 Speaker Assembly LH)






I 1 Rear Power Window Regulator Switch Assembly RH
 I 2 Rear Power Window Regulator Motor Assembly RH
 I 3 Rear Door with Motor Lock Assembly RH
 I 4 Rear Speaker Assembly RH

J 1 Rear Power Window Regulator Switch Assembly LH
 J 2 Rear Power Window Regulator Motor Assembly LH
 J 3 Rear Door with Motor Lock Assembly LH
 J 4 Rear Speaker Assembly LH


cardiagn.com



cardiagn.com











* 3:w/ Entry & Start System
 * 4:w/o Entry & Start System




- K 1 Front Door Courtesy Light Switch Assembly LH
- K 2 Front Door Courtesy Light Switch Assembly RH
- K 3 Rear Door Courtesy Light Switch Assembly LH
- K 4 Rear Door Courtesy Light Switch Assembly RH
- K 5 Rear Combination Light LH
- K 6 Rear Combination Light RH
- K 7 No. 2 Room Light Assembly
- K 8 Front Seat Inner Belt Assembly LH
- K 9 Front Seat Inner Belt Assembly RH
- K 10 Door Control Receiver
- K 11 No. 2 Indoor Electrical Key Antenna Assembly
- K 12 Door Control Receiver
- K 13 Rear Indoor Electrical Key Antenna
- K 14 Rear Seat Inner with Center Belt Assembly LH (Rear Seat LH)
- K 15 Rear Seat Inner Belt Assembly RH
- K 16 Rear Seat Inner with Center Belt Assembly LH (Rear Seat Center)
- K 17 Fuel Sender Gage Assembly

cardiagn.com




cardiagn.com




- K 20 Rear Power Point Socket Assembly
- K 21 Side Airbag Sensor Assembly LH
- K 22 Side Airbag Sensor Assembly RH
- K 23 No. 2 Side Airbag Sensor Assembly LH
- K 24 No. 2 Side Airbag Sensor Assembly RH
- K 25 Front Seat Outer Belt Assembly LH
- K 26 Front Seat Outer Belt Assembly RH
- K 27 Curtain Shield Airbag Assembly LH
- K 28 Curtain Shield Airbag Assembly RH
- K 29 Front Seat Airbag Assembly LH
- K 30 Front Seat Airbag Assembly RH
- K 37 Tire Pressure Warning ECU and Receiver

cardiagn.com



cardiagn.com

- * 5:w/ Roof Sunshade System
- * 6:w/o Roof Sunshade System
- * 9:w/ Rear Fog Light
- * 10:Hong Kong
- * 11:Before May 2013 Production
- * 12:From May 2013 Production



- L 1 Map Light Assembly
- L 2 Map Light Assembly
- L 3 No. 1 Room Light Assembly
- L 4 Inner Rear View Mirror Assembly
- L 5 Rain Sensor
- L 7 Slide Roof Motor Switch
- L 8 Amplifier Microphone Assembly

- M 1 Rear Light Assembly LH
- M 2 Rear Light Assembly RH
- M 4 Rear Light Assembly RH

- N 1 Rear Height Control Sensor Sub-Assembly

- O 1 Center Stop Light Assembly

- P 1 Rear Wiper Motor Assembly
- P 2 Rear Wiper Motor Assembly
- P 3 Rear Television Camera Assembly
- P 4 License Plate Light Assembly RH
- P 5 License Plate Light Assembly LH
- P 6 Rear Window Defogger (Back Door Glass)
- P 7 Back Door Lock Assembly
- P 8 Back Door Opener Switch Assembly
- P 9 Rear Television Camera Assembly


- Q 1 Rear Window Defogger (Back Door Glass)

- V 1 Rear Speed Sensor LH


- W 1 Rear Speed Sensor RH

- a 1 Sliding Roof Drive Gear Assembly


cardiagn.com




cardiagn.com




JK1
White




JK1
White




La1
White




MK1
White




NK1
White




OK1
White




cardiagn.com



cardiagn.com




- * 1:w/ VSC
- * 2:w/o VSC
- * 3:w/ Entry & Start System
- * 4:w/o Entry & Start System










- F 1 Combination Meter Assembly
- F 2 Hazard Warning Signal Switch Assembly
- F 3 Combination Meter Assembly
- F 4 DLC3
- F 5 Spiral Cable Sub-Assembly
- F 6 Power Steering ECU Assembly
- F 7 Outer Mirror Switch Assembly
- F 8 Headlight Leveling Switch
- F 9 Headlight Dimmer Switch Assembly
- F 11 Windshield Wiper Switch Assembly
- F 12 Windshield Wiper Switch Assembly
- F 13 Ignition or Starter Switch Assembly
- F 14 Key Inter Lock Solenoid
- F 15 Un-Lock Warning Switch Assembly
- F 16 Center Airbag Sensor Assembly
- F 17 Spiral Cable Sub-Assembly
- F 19 Lower No. 1 Instrument Panel Airbag Assembly
- F 20 Airbag Cut Off Switch Cylinder Sub-Assembly
- F 21 Telltale Light Assembly
- F 22 Parking Brake Switch Assembly
- F 23 Shift Lock Control ECU Sub-Assembly
- F 24 Shift Lock Control ECU Sub-Assembly
- F 25 Transmission Control Switch
- F 26 Shift Position Indicator (Floor Shift Position Indicator Housing Sub-Assembly)
- F 27 Power Outlet Socket Assembly
- F 30 Steering Sensor


cardiagn.com



cardiagn.com























- * 3:w/ Entry & Start System
- * 4:w/o Entry & Start System
- * 7:Refer to the Service Bulletin
for the installation position of the parts.
- * 8:Automatic A/C
- * 11:Manual A/C
- * 12:Before Sep. 2013 Production
- * 13:From Sep. 2013 Production
- * 14:Before May 2014 Production






- F 31 Cooler (Duct Sensor) Thermistor
- F 32 No. 1 Cooler Thermistor
- F 33 Cooler (Room Temperature Sensor) Thermistor
- F 34 Blower Resistor
- F 35 Blower with Fan Motor Sub-Assembly
- F 36 Blower with Fan Motor Sub-Assembly
- F 37 No. 3 Heater Control Sub-Assembly
- F 38 No. 1 Heater Control Sub-Assembly
- F 39 No. 2 Heater Control Sub-Assembly
- F 40 A/C Control Assembly
- F 41 A/C Amplifier Assembly
- F 42 A/C Amplifier Assembly
- F 44 Heater Switch Assembly
- F 45 Radio Receiver Assembly , Radio & Display Receiver Assembly
- F 46 Radio Receiver Assembly , Radio & Display Receiver Assembly
- F 47 Radio Receiver Assembly , Radio & Display Receiver Assembly
- F 48 Radio & Display Receiver Assembly
- F 53 No. 1 Stereo Jack Adapter Assembly
- F 54 Transponder Key ECU Assembly
- F 55 Transponder Key Amplifier
- F 56 Theft Warning Indicator Light Assembly
- F 57 VSC Off Switch
- F 58 Deceleration Sensor
- F 59 Engine Switch
- F 60 ID Code Box

cardiagn.com



cardiagn.com
















- * 5:w/ Stop & Start System
- * 6:w/o Stop & Start System
- * 7:Refer to the Service Bulletin for the installation position of the parts.
- * 12:Before Sep. 2013 Production
- * 13:From Sep. 2013 Production
- * 15:From May 2014 Production

- F 61 Steering Lock Actuator Assembly
- F 62 No. 1 Indoor Electrical Key Antenna Assembly
- F 63 Certification ECU Assembly
- F 64 Certification ECU Assembly
- F 65 Certification ECU Assembly
- F 66 No. 1 Interior Illumination Light Assembly RH
- F 67 No. 1 Interior Illumination Light Assembly LH
- F 68 Transmission Control ECU Assembly
- F 69 Transmission Shift Main Switch
- F 70 Shift Position Indicator (Floor Shift Position Indicator Housing Sub-Assembly)
- F 71 Shift Lever Position Sensor
- F 72 Windshield Wiper Relay Assembly
- F 73 Automatic Light Control Sensor
- F 74 Power Management Control ECU
- F 75 Engine Stop and Start ECU
- F 76 Main Body ECU
- F 82 Junction Connector
- F 83 Junction Connector
- F 84 Junction Connector
- F 85 Junction Connector
- F 89 Radio Receiver Assembly , Radio & Display Receiver Assembly
- F 91 Radio & Display Receiver Assembly
- F 92 Option Connector (Navigation Receiver)
- F 93 Extension Module
- F 94 Tire Pressure Warning Reset Switch
- F 95 Transponder Key Coil


cardiagn.com



cardiagn.com


F 74

White




F 75

Black




F 76

White




F 82

Blue




F 83

Gray




F 84

Black




F 85

Black




F 89

Gray




F 91

White




F 92

White



F 93

Gray




F 94

Black




F 95

Black



cardiagn.com



- A 36 Accelerator Pedal Sensor Assembly
- A 38 Stop Light Switch Assembly
- A 39 Clutch Start Switch Assembly
- A 40 Clutch Switch Assembly
- A 42 Power Steering ECU Assembly
- A 44 Quick Heater Assembly
- A 46 Transmission Control ECU Assembly
- A 47 Transmission Control ECU Assembly
- A 48 Transmission Control ECU Assembly
- A 52 Power Management Control ECU
- A 53 Engine Stop and Start ECU
- A 61 Junction Connector
- A 62 Junction Connector
- A 63 Junction Connector
- A 64 Junction Connector
- A 76 Stop Light Switch Assembly

- K 31 Center Airbag Sensor Assembly
- K 32 Center Airbag Sensor Assembly
- K 33 Center Airbag Sensor Assembly
- K 34 Center Airbag Sensor Assembly

















- S 1 Instrument Panel Passenger without Door Airbag Assembly

- T 1 Radio & Display Receiver Assembly
- T 2 Extension Module
- T 3 Radio & Display Receiver Assembly
- T 4 Extension Module















- U 1 Seat Heater Switch

- z 1 Driver Side Squib Circuit , Spiral Cable Sub-Assembly
- z 2 Steering Pad Switch Assembly , Spiral Cable Sub-Assembly
- z 4 A/C Amplifier Assembly , A/C Blower Assembly
- z 5 Power Steering ECU Assembly , Power Steering Motor Assembly
- z 6 Power Steering ECU Assembly , Power Steering Torque Sensor
- z 7 Cruise Control Main Switch , Spiral Cable Sub-Assembly


cardiagn.com




cardiagn.com




cardiagn.com






cardiagn.com




cardiagn.com


KF1
White




KF2
White




KF3
White




LF1
White


















cardiagn.com












- F 1 Combination Meter Assembly
- F 2 Hazard Warning Signal Switch Assembly
- F 3 Combination Meter Assembly
- F 4 DLC3
- F 5 Spiral Cable Sub-Assembly
- F 6 Power Steering ECU Assembly
- F 7 Outer Mirror Switch Assembly
- F 8 Headlight Leveling Switch
- F 9 Headlight Dimmer Switch Assembly
- F 10 Headlight Dimmer Switch Assembly
- F 11 Windshield Wiper Switch Assembly
- F 12 Windshield Wiper Switch Assembly
- F 13 Ignition or Starter Switch Assembly
- F 14 Key Inter Lock Solenoid
- F 15 Un-Lock Warning Switch Assembly
- F 16 Center Airbag Sensor Assembly
- F 17 Spiral Cable Sub-Assembly
- F 19 Lower No. 1 Instrument Panel Airbag Assembly
- F 20 Airbag Cut Off Switch Cylinder Sub-Assembly
- F 21 Telltale Light Assembly
- F 22 Parking Brake Switch Assembly
- F 23 Shift Lock Control ECU Sub-Assembly
- F 24 Shift Lock Control ECU Sub-Assembly
- F 25 Transmission Control Switch
- F 26 Shift Position Indicator (Floor Shift Position Indicator Housing Sub-Assembly)
- F 27 Power Outlet Socket Assembly
- F 28 Pattern Select Switch Assembly
- F 30 Steering Sensor


cardiagn.com



cardiagn.com






















cardiagn.com






- F 32 No. 1 Cooler Thermistor
- F 33 Cooler (Room Temperature Sensor) Thermistor
- F 34 Blower Resistor
- F 35 Blower with Fan Motor Sub-Assembly
- F 36 Blower with Fan Motor Sub-Assembly
- F 37 No. 3 Heater Control Sub-Assembly
- F 38 No. 1 Heater Control Sub-Assembly
- F 39 No. 2 Heater Control Sub-Assembly
- F 40 A/C Control Assembly
- F 41 A/C Amplifier Assembly
- F 42 A/C Amplifier Assembly
- F 45 Radio Receiver Assembly , Radio & Display Receiver Assembly
- F 46 Radio Receiver Assembly , Radio & Display Receiver Assembly
- F 47 Radio Receiver Assembly , Radio & Display Receiver Assembly
- F 48 Radio & Display Receiver Assembly
- F 53 No. 1 Stereo Jack Adapter Assembly
- F 54 Transponder Key ECU Assembly
- F 55 Transponder Key Amplifier
- F 56 Theft Warning Indicator Light Assembly
- F 57 VSC Off Switch
- F 58 Deceleration Sensor
- F 59 Engine Switch
- F 60 ID Code Box

cardiagn.com












cardiagn.com



















- F 61 Steering Lock Actuator Assembly
- F 62 No. 1 Indoor Electrical Key Antenna Assembly
- F 63 Certification ECU Assembly
- F 64 Certification ECU Assembly
- F 65 Certification ECU Assembly
- F 66 No. 1 Interior Illumination Light Assembly RH
- F 67 No. 1 Interior Illumination Light Assembly LH
- F 72 Windshield Wiper Relay Assembly
- F 73 Automatic Light Control Sensor
- F 74 Power Management Control ECU
- F 76 Main Body ECU
- F 77 Main Body ECU
- F 79 Double Lock Door Control Relay Assembly
- F 80 Oxygen Sensor (Bank 1 Sensor 2)
- F 82 Junction Connector
- F 83 Junction Connector
- F 84 Junction Connector
- F 85 Junction Connector
- F 89 Radio Receiver Assembly , Radio & Display Receiver Assembly
- F 90 Engine Stop and Start ECU
- F 91 Radio & Display Receiver Assembly
- F 92 Option Connector (Navigation Receiver)
- F 93 Extension Module
- F 94 Tire Pressure Warning Reset Switch
- F 95 Transponder Key Coil
- F 96 Oxygen Sensor (Bank 1 Sensor 2)


cardiagn.com



cardiagn.com



cardiagn.com



- A 26 Parking Brake Switch Assembly
- A 36 Accelerator Pedal Sensor Assembly
- A 37 Stop Light Switch Assembly
- A 38 Stop Light Switch Assembly
- A 39 Clutch Start Switch Assembly
- A 41 Clutch Switch Assembly
- A 42 Power Steering ECU Assembly
- A 43 Headlight Leveling ECU Assembly
- A 44 Quick Heater Assembly
- A 52 Power Management Control ECU
- A 61 Junction Connector
- A 62 Junction Connector
- A 63 Junction Connector
- A 64 Junction Connector
- A 72 Engine Stop and Start ECU
- A 73 Engine Stop and Start ECU
- A 76 Stop Light Switch Assembly

- K 31 Center Airbag Sensor Assembly
- K 32 Center Airbag Sensor Assembly
- K 33 Center Airbag Sensor Assembly
- K 34 Center Airbag Sensor Assembly



















- S 1 Instrument Panel Passenger without Door Airbag Assembly

- T 1 Radio & Display Receiver Assembly
- T 2 Extension Module
- T 3 Radio & Display Receiver Assembly
- T 4 Extension Module













- U 1 Seat Heater Switch

- z 1 Driver Side Squib Circuit , Spiral Cable Sub-Assembly
- z 2 Steering Pad Switch Assembly , Spiral Cable Sub-Assembly
- z 4 A/C Amplifier Assembly , A/C Blower Assembly
- z 5 Power Steering ECU Assembly , Power Steering Motor Assembly
- z 6 Power Steering ECU Assembly , Power Steering Torque Sensor
- z 7 Cruise Control Main Switch , Spiral Cable Sub-Assembly


cardiagn.com




cardiagn.com




cardiagn.com






cardiagn.com




cardiagn.com


KF1
White




KF2
White



KF3
White



LF1
White



cardiagn.com