


Mercury Mountaineer 1997 – 2001 fuse box diagram

Passenger compartment fuse panel



Mercury Mountaineer First Generation – fuse box – passenger compartment

No.	A	Protected components
1	7.5	Power Mirror Switch, Power Antenna, Memory Seat ('00-'01)

2	7.5	'98-'01: Blower Motor Relay, Air Bag Diagnostic Monitor, Passive Deactivation (PAD) Module ('98)
	7.5	'97: High-mount Brakelamp
3	7.5	'98-'01: Left Stop/Turn Trailer Tow Connector
	15	'97: Parking Lamps
4	10	Left Headlamp
5	10	Data Link Connector (DLC)
6	7.5	'99-'01: Rear Blower Motor (Without EATC)
	7.5	'97-'98: Air Bag System, Blower Relay, Passive Deactivation (PAD) Module ('98)
7	7.5	'98-'01: Right Stop/Turn Trailer Tow Connector

	7.5	'97: Illumination switches
8	10	Right Headlamp, Foglamp Relay, Daytime Running Lamps (DRL) Module ('98)
9	7.5	'98-'01: Brake Pedal Position Switch
	10	'97: Autolamps
10	7.5	'98-'01: Speed Control/Amplifier Assembly, Generic Electronic Module (GEM), Shift Lock Actuator, Blend Door Actuator, A/C – Heater Assembly, Flasher, Overhead Console ('99-'01), Load Leveling Module ('99-'01), Brake Pressure Switch ('98), Main Light Switch ('98), RABS Resistor ('98), A/C – Heater Assembly
	7.5	'97: Rear Blower, Speed Control, Generic Electronic Module (GEM), Brake Interlock, Overhead Console
11	7.5	Instrument Cluster, Main Light Switch ('98), RABS Resistor ('98)

12	7.5	'98-'01: Washer Pump Relay, Rear Washer Pump Relay
	10	'97: Liftgate Wiper/Washer, Front Washer
13	20	'98-'01: Brake Pedal Position Switch, Brake Pressure Switch
	15	'97: Brake on/off Switch
14	10	'98-'01: 4 Wheel Anti-Lock Brake System (4WABS) Module, 4WABS Main Relay
	10	'97: Anti-Lock Brake System
	20	'98: Rear Anti-Lock Brake System (RABS) Module
15	7.5	Instrument Cluster, Air Bag System ('97)
16	30	Windshield Wiper Motor ('98-'01), Wiper Hi-Lo Relay ('98-'01), Wiper Run/Park Relay

17	25	'98-'01: Cigar Lighter
	15	'97: Cigar Lighter
18	25	'99-'01: Drivers Unlock Relay, All Unlock Relay, All Lock Relay, Power Seats
	15	'97: A/C System
	15	'98: Drivers Unlock Relay, All Unlock Relay, All Lock Relay
19	25	'98-'01: PCM Power Diode
	25	'97: Ignition Coil, PCM System
20	7.5	RAP Module ('98-'01), Generic Electronic Module (GEM), Radio, Cellular Phone ('99-'01), Power Antenna ('97), Anti-theft ('97)

21	15	Flasher (Hazard)
22	20	Auxiliary Power Socket
	10	Turn Signals
23	—	'99-'01: Not Used
	10	'97: Rear Wiper System
	15	'98: Turn Signals
24	7.5	'99-'01: Clutch Pedal Position (CPP) Switch, Starter Interrupt Relay, Anti-Theft
	10	'97: Anti-theft Relay
	—	'98: Not Used


25	7.5	Generic Electronic Module (GEM), Instrument Cluster, Securi-Lock ('99-'01)
26	10	'98-'01: Battery Saver Relay, Electronic Shift Relay, Interior Lamp Relay, Electronic Shift Control Module, Power Window Relay ('98), Shift Control Module ('98), Transmission Control ('98)
	10	'97: 4R70W Overdrive, Daytime Running Lamps (DRL) System, Backup Lamps, Rear Defroster Relay
27	15	'99-'01: Daytime Running Lamps (DRL), Backup Lamps Switch, DTR Sensor
	10	'97: Underhood Lamp, Map Lights, Glove Box Lamp, Overhead Lamp, Visor Lamps, Accessory Delay, Dimmer Switch Illumination
	15	'98: Switch, Daytime Running Lamps (DRL), Backup Lamps Switch, DTR Sensor, Instrument Illumination Dimming Module, Dome/Map Lamp, GEM, Electric Shift, Interior Lights, Glove Box Lamp and Switch

28	7.5	Generic Electronic Module (GEM), Radio ('98-'01), Memoiy Seat ('99-'01)
29	25	'00-'01: Radio
	10	'97: Audio System
	15	'98: Radio
	10	'99: Radio
30	15	'98-'01: Park Lamp/Trailer Tow Relay
	—	'97: Not Used
31	—	'98-'01: Not Used
	7.5	'97: Rear Blower Motor Relay

32	10	'99-'01: Heated Mirror
	7.5	'97: Heated Rear Window
	10	'98: Rear Blower
33	15	Headlamps, Daytime Running Lamps (DRL) Module, Instrument Cluster
34	7.5	'98-'01: Rear Integrated Control Panel, CD
	7.5	'97: Luxury Audio System
35	7.5	'99-'01: Rear Blower Motor (With EATC)
	—	'97: Not Used
	10	'98: RABS Test Connector

36	7.5	'98-'01: EATC Memory ('99-'01), CD, Rear Integrated Control Panel, Memory Seat, Message Center
	—	'97: Not Used

Engine Compartment Fuse Box ('97)



Mercury Mountaineer – fuse box diagram – engine compartment

No.	A	Fused component

Maxi fuses		
1	30	Rear window defrost
2	30	PCM power relay
3	20	Fuel system, anti-theft system
4	20	Headlamps
5	30	ABS system
6	30	ABS system
7	20	Trailer park LP and trailer stop LP
8	30	Battery saver relay and headlamp relay


9	50	Blower motor
10	30	Power locks, power windows and power
11	20	PCM memory and
12	50	Air ride control relay
13	60	Instrument panel fuse
14	60	Ignition
Mini fuses		
1	30	JBL system
2	15	Rear wiper system

3	30	Power point
4	20	4WD system
5	15	Air suspension system
6	15	Alternator system
7	10	Air bag system
8	15	DRL/Fog lamps/Off-road lamps
9	—	Not used
10	—	Not used
11	20	HEGO system

Relay	
1	Wiper run relay
2	Horn relay
3	Wiper HI/LO relay
4	WOT A/C relay
5	PCM power relay
6	Fuel pump relay
Diode	
1	ABS diode

2	PCM diode
---	-----------

Engine Compartment Fuse Box ('98-'01)



Mercury Mountaineer – fuse box diagram – engine compartment

No.	A	Protected components
Maxi Fuses		
1	60	'99-'01: I/P Fuse Panel fuses 1,9, and 13

	50	'98: I/P Fuse Panel
2	40	Blower Motor Relay
3	50	4 Wheel Anti-Lock Brake System (4WABS) Module
4	30	'99-'01: Power Moon Roof, Accessory Relay Delay ('01), Power Windows ('99-'00), Power Seat ('99-'00)
	20	'98: Mainlight Switch, Instrument Cluster
5	50	Ignition Switch, Starter Relay
6	20	Transfer Case Relay
7	—	Not Used
8	20	Air Suspension (Automatic Ride Control ARC Switch Off/On Switch)

9	40	Air Suspension (Automatic Ride Control Relay)
10	30	PCM Power Relay
Mini Fuses		
1	10	A/C Relay
2	30	'99-'01: Heated Seats
	20	'98: Auxiliary Power Point
3	30	'99-'01: Heated Backlight
	—	'98: Not Used
4	15	Fog Lamps and Daytime Running Lamps

5	—	'99-'01: Not Used
	10	'98: Air Bag Diagnostic Monitor
6	10	Powertrain Control Module
7	30	4 Wheel Anti-Lock System (4WABS) Module
8	15	'99-'01: Rear Wiper Motor
	30	'98: PCM Relay
9	20	Fuel Pump Relay and RAP Module
10	15	Horn Relay
11	15	Parklamps Relay and Mainlight Switch

12	30	Mainlight Switch and Multifunction Switch
13	15	Heated Oxygen Sensor, EGR Vacuum Regulator, EVR Solenoid, Camshaft Position (CMP) Sensor, Canister Vent Solenoid, A4LD Automatic Transmission ('98)
14	30	Generator/Voltage Regulator
15	—	Not Used
Relay		
1	Wiper Park	
2	A/C	
3	Wiper High/Low	

4	PCM Power
5	Fuel Pump
6	Starter
7	Horn
8	'99-'01: Rear Wiper Down
	'98: Washer Pump
9	Blower Motor
10	'99-'01: Rear Wiper Up
	'98: Fog Lamp

Diode / Resistor	
1	'99-'01: Not Used
	'98: Resistor: Fuse 7
1	'00-'01: Daytime Running Lamps Diode
	'98: Anti-Lock Brakes Indicator Diode
	'99: Not Used
2	Electronic Engine Controls Diode