

DIAGNOSTIC TROUBLE CODE CHART

If a DTC is displayed during the DTC check, check the circuit listed for that code in the table below and proceed to the page given.

DTC No. (See Page)	Detection Item	Trouble Area	MIL *	Memory
P0500 (DI-174)	Vehicle Speed Sensor Malfunction (Vehicle Speed Sensor)	• Open or short in speed signal circuit • ABS speed sensor • Combination meter • ECM • ABS ECU • Automatic transaxle (clutch, brake or gear etc.)	●	○
P0710 (DI-177)	Transmission Fluid Temperature Sensor Malfunction	• Open or short in ATF temperature sensor circuit • ATF temperature sensor • ECM	●	○
P0750 (DI-179)	Shift Solenoid A Malfunction (Shift Solenoid Valve No.1)	• Shift solenoid valve No.1 is stuck open or closed • Valve body is blocked up or stuck • Automatic transaxle (clutch, brake or gear etc.)	●	○
P0753 (DI-181)	Shift Solenoid A Electrical Malfunction (Shift Solenoid Valve No.1)	• Open or short in shift solenoid valve No.1 circuit • Shift solenoid valve No.1 • ECM	●	○
P0755 (DI-179)	Shift Solenoid B Malfunction (Shift Solenoid Valve No.2)	• Shift solenoid valve No.2 is stuck open or closed • Valve body is blocked up or stuck • Automatic transaxle (clutch, brake or gear etc.)	●	○
P0758 (DI-181)	Shift Solenoid B Electrical Malfunction (Shift Solenoid Valve No.2)	• Open or short in shift solenoid valve No.2 circuit • Shift solenoid valve No.2 • ECM	●	○
P0770 (DI-185)	Shift Solenoid E Malfunction (Shift Solenoid Valve SL)	• Shift solenoid valve SL is stuck open or closed • Valve body is blocked up or stuck • Lock-up clutch • Automatic transaxle (clutch, brake or gear etc.)	●	○
P0773 (DI-187)	Shift Solenoid E Electrical Malfunction (Shift Solenoid Valve SL)	• Open or short in shift solenoid valve SL circuit • Shift solenoid valve SL • ECM	●	○
P1520 (DI-190)	Stop Light Switch Signal Malfunction	• Open or short in stop light switch circuit • Stop light switch • ECM	●	○
P1705 (DI-191)	NC2 Revolution Sensor Circuit Malfunction (Direct Clutch Speed Sensor)	• Open or short in direct clutch speed sensor circuit • Direct clutch speed sensor • ECM	●	○
P1765 (DI-193)	Linear Solenoid for Accumulator Pressure Control Circuit Malfunction (Shift Solenoid Valve SLN)	• Open or short in shift solenoid valve SLN circuit • Shift solenoid valve SLN • ECM	●	○
P1780 (DI-197)	Park/Neutral Position Switch Malfunction	• Short in park/neutral position switch circuit • Park/neutral position switch • ECM	●	○

*: ●... MIL lights up