

ENGINE

HOW TO PROCEED WITH TROUBLESHOOTING

DI21L-02

Troubleshoot in accordance with the procedure on the following page.

