

FUEL TANK AND LINE

SF01S-01

PRECAUTION

- Always use new gaskets when replacing the fuel tank or component parts.
- Apply the proper torque to all parts tightened.