
















# SUSPENSION AND AXLE












## SST (Special Service Tools)

PP0PX-03




|                                                                                     |                                                       |                                |
|-------------------------------------------------------------------------------------|-------------------------------------------------------|--------------------------------|
|    | 09023-00100 Union Nut Wrench 10 mm                    | Rear suspension                |
|    | 09223-56010 Crankshaft Rear Oil Seal Replacer         | Front drive shaft              |
|    | 09238-47012 Water Pump Bearing Remover & Replacer     | Front suspension               |
|    | 09240-00020 Wire Gauge Set                            | Front drive shaft              |
|    | 09309-36010 Transmission Rear Bearing Replacer        | Front drive shaft              |
|  | 09309-37010 Transmission Bearing Replacer             | Rear suspension                |
|  | 09310-35010 Countershaft Bearing Replacer             | Front axle                     |
|  | 09316-2001 1 Transfer Bearing Replacer                | Front drive shaft              |
|  | 09316-6001 1 Transmission & Transfer Bearing Replacer | Front axle<br>Front suspension |
|  | (09316-0001 1) Replacer Pipe                          |                                |
|  | (09316-00041) Replacer "C"                            |                                |
|  | 09520-00031 Rear Axle Shaft Puller                    | Front axle                     |

## PREPARATION - SUSPENSION AND AXLE

|                                                                                     |                                                        |                                 |
|-------------------------------------------------------------------------------------|--------------------------------------------------------|---------------------------------|
|    | 09521-24010 Drive Shaft Boot Clamping Tool             | Front drive shaft               |
|    | 09527-1701 1 Rear Axle Shaft Bearing Remover           | Front axle                      |
|    | 09555-55010 Differential Drive Pinion Bearing Replacer | Front axle<br>Front drive shaft |
|    | 09608-16042 Front Hub Bearing Adjusting Tool           | Front drive shaft               |
|    | (09608-02021) Bolt & Nut                               |                                 |
|    | (09608-02041) Retainer                                 |                                 |
|  | 09608-32010 Steering Knuckle Oil Seal Replacer         | Front axle<br>Front suspension  |
|  | 09610-20012 Pitman Arm Puller                          | Front axle                      |
|  | 09628-1001 1 Ball Joint Puller                         | Front axle<br>Rear axle         |
|  | 09628-6201 1 Ball Joint Puller                         | Front axle<br>Front suspension  |
|  | 09649-17010 Steering Knuckle Tool                      | Front suspension                |
|  | 09710-04081 Base                                       | Front suspension                |
|  | 09710-14013 Rear Suspension Bushing Tool Set           | Rear suspension                 |

|                                                                                     |                                            |                   |
|-------------------------------------------------------------------------------------|--------------------------------------------|-------------------|
|    | (09710-00021) Pipe                         |                   |
|    | 09727-30021 Coil Spring Compressor         | Front suspension  |
|    | 09729-22031 Front Spring Upper Seat Holder | Front suspension  |
|    | 09950-00020 Bearing Remover                | Front drive shaft |
|    | 09950-4001 1 Puller B Set                  | Rear suspension   |
|    | (09951-04010) Hanger 150                   |                   |
|  | (09952-04010) Slide Arm                    |                   |
|  | (09953-04010) Center Bolt 100              |                   |
|  | (09953-04030) Center Bolt 200              |                   |
|  | (09954-04020) Arm 100                      |                   |
|  | (09955-04031) Claw No.3                    |                   |
|  | (09955-04051) Claw No.5                    |                   |
|  | (09957-04010) Attachment                   |                   |

## PREPARATION - SUSPENSION AND AXLE

|                                                                                   |                           |                 |
|-----------------------------------------------------------------------------------|---------------------------|-----------------|
|  | (09958-0401 1) Holder     |                 |
|  | 09950-60010 Replacer Set  |                 |
|  | (09951-00400) Replacer 40 | Front axle      |
|  | (09951-00560) Replacer 56 | Rear suspension |
|  | 09950-70010 Handle Set    | Front axle      |
|  | (09951-07100) Handle 100  |                 |