



STARTER COMPONENTS

ST02H-02




B00845



◆ Non-reusable part

B01154

Magnetic Switch Assembly



B06429