

Enclosure 1 to SI 21 02 96 (141), edition 06/2006

<i>Trade name</i>	<i>BMW part number</i>	<i>Container size</i>
BMW DOT 4 low viscosity brake fluid	83 13 0 139 895	0.25-litre can
BMW DOT 4 low viscosity brake fluid	83 13 0 139 896	0.5-litre can
BMW DOT 4 low viscosity brake fluid	83 13 0 139 897	1.0-litre can
BMW DOT 4 low viscosity brake fluid	83 13 0 139 898	5.0-litre can
BMW DOT 4 low viscosity brake fluid	83 13 0 139 899	30.0-litre canister
BMW DOT 4 low viscosity brake fluid	83 13 0 139 900	60.0-litre barrel

Note:

Please refer to group 34 for detailed information on brake fluids.

Please refer to SI 34 03 96 (150)

Enclosure 2 to SI 21 02 96 (141), edition 06/2006

<i>Trade name</i>	<i>BMW part number</i>	<i>Container size</i>
Pentosin CHF11S	81 22 9 407 758	1-litre can

(*) all SMG variants

Enclosure 3 to SI 21 02 96 (141), edition 06/2018

Brake cylinder paste

For repair work on the clutch master or slave cylinder

Coat cylinder bore and grooved collar slightly.

<i>Trade name</i>	<i>BMW part number</i>	<i>Container size</i>
ATE brake cylinder paste	83 19 9 407 854	180 g tube
Syntheso Glep 1 lubricating grease	83 23 9 407 778	100 g tube

Grease in the clutch region

For greasing

- the spline grooves and the shaft extension of the transmission input shaft,
- the release lever (on the contact surfaces of the ball pin, release unit and piston rod of the clutch slave cylinder),

the grease listed below must be used according to the repair instructions.

<i>Trade name</i>	<i>BMW part number</i>	<i>Container size</i>
Grease MI-Setral-43 N	83 23 2 152 082	40g tube