

27. Fuel Filter

A: SPECIFICATION

Fuel filter forms a single unit with fuel pump.

Refer to “Fuel Pump” for removal and installation.

<Ref. to FU(H4SO)-56, REMOVAL, Fuel Pump.>

<Ref. to FU(H4SO)-57, INSTALLATION, Fuel Pump.>