

1. General Description

A: SPECIFICATION

Specifications for the turbo model are included in the SC(H4SO) section. <Ref. to SC(H4SO)-2, General Description.>

ENGINE (DIAGNOSTICS)

EN(H4DOTC)(diag)

	Page
1. Basic Diagnostic Procedure	2
2. Check List for Interview	3
3. General Description	5
4. Electrical Component Location	8
5. Engine Control Module (ECM) I/O Signal	17
6. Engine Condition Data	27
7. Data Link Connector	28
8. General Scan Tool	29
9. Subaru Select Monitor	34
10. Read Diagnostic Trouble Code (DTC)	41
11. Inspection Mode	42
12. Drive Cycle	47
13. Clear Memory Mode	52
14. Compulsory Valve Operation Check Mode	53
15. System Operation Check Mode	55
16. Malfunction Indicator Light	57
17. Diagnostics for Engine Starting Failure	66
18. Diagnostic Procedure for Subaru Select Monitor Communication	78
19. List of Diagnostic Trouble Code (DTC)	80
20. Diagnostic Procedure with Diagnostic Trouble Code (DTC)	88
21. General Diagnostic Table	366