


Starter System

WIRING SYSTEM

54.Starter System

A: WIRING DIAGRAM

1. NON-TURBO MODEL (WITHOUT PUSH BUTTON START)



WI-40958






Starter System

WIRING SYSTEM

1b

1b

LIST OF CONNECTORS



RELAY HOLDER




Starter System

WIRING SYSTEM

2. NON-TURBO MODEL (WITH PUSH BUTTON START)

2a

2a



WI-40959


Starter System

WIRING SYSTEM

2b

2b

LIST OF CONNECTORS




Starter System

WIRING SYSTEM

3. TURBO MODEL (WITHOUT PUSH BUTTON START)

3a

3a



WI-40961


Starter System

WIRING SYSTEM

3b

3b

LIST OF CONNECTORS




Starter System

WIRING SYSTEM

4. TURBO MODEL (WITH PUSH BUTTON START)

4a

4a



WI-40963

Starter System

WIRING SYSTEM

4b

4b

LIST OF CONNECTORS

