

## Clear Memory Mode

TIRE PRESSURE MONITORING SYSTEM (DIAGNOSTICS)

---

### 7. Clear Memory Mode

#### A: OPERATION

- 1) On the «Main Menu» display, select {2. Each System Check}.
- 2) On the «System Selection Menu», select {Tire Pressure Monitor}.
- 3) After the {Tire pressure monitor} is displayed, select [OK].
- 4) On the «Tire pressure monitor diagnosis», select {Clear Memory}.
- 5) When “Done” and “Turn Ignition Switch OFF” are shown on the display screen, end the Subaru Select Monitor and turn the ignition switch to OFF.

#### NOTE:

For details concerning the operation procedure, refer to the “PC application help for Subaru Select Monitor”.