


CYLINDER BLOCK COMPONENTS

EM162-02

1ZZ-FE:




N·m (kgf·cm, ft·lbf) : Specified torque

◆ Non-reusable part

A10449

2ZZ-GE:



N

N·m (kgf·cm, ft·lbf) : Specified torque



◆ Non-reusable part

A12960


Diagram illustrating the components of a piston and connecting rod assembly, labeled as follows:

- No.1 Compression Ring
- No.2 Compression Ring
- Oil Ring (Expander)
- Oil Ring (Side Rail)
- Piston
- ◆ Snap Ring
- Piston Pin
- ◆ Connecting Rod Bushing
- Connecting Rod
- Connecting Rod Bearing

1st Turn (200, 15)
2nd Turn 90°



◆Non-reusable part

2ZZ-GE:

N·m (kgf·cm, ft·lbf) : Specified Torque

N ◆ Non-reusable part

A12961