


Buick Century 1995 fuse box diagram

Instrument Panel Fuse Block

The fuse panel is located inside the glove box, on the left side.



Buick Century – fuse box diagram – instrument

panel

Fuse	Usage
ECM	Power Train Control Module
TNJ/COIL	Fuel Injectors
UNLOCK	Auto Door Locks (Remove this fuse to disable the automatic door unlock)
FAN/ALT	Electric Fan, Starter and Generator, Seq. Fuel Inj (V6), Cruise Control, Anti-Lock Brakes
TURN B/U	Back-up Lamps
AIR BAG	Supplemental Inflatable Restraint (Air Bag)
TAIL	Tail, Park. Side Marker, License Plate, Stop/Turn Signal
HTR A/C	Heater/Air Conditioner Blower Controls
GAUGES	I/P Cluster, Warning Indicators, Torque Converter Clutch, Audible Warning System, Trunk Release, Brake Warning Indicator, Rear Defog Switch, Remote Keyless Entry, Headlamps, Air Bag (DERM)
STOP HAZ	Stop Lamps, Hazard Flashers
CTSY	Interior, Underhood, Courtesy, UP, Trunk Lamps. Door Locks, Horn Relay, Passive Restraint System, Deck Lid Release, Power Antenna Remote Keyless Entry: Vanity Mirror
WDO	Power Windows
INST LPS	Illumination for: I/P, Radio, Pod Lamps, Ashtray, Console Lamp, Heater-A/C Control, Defog Switch, Headlamp Switch, Power Antenna, Lighted Vanity Mirrors
RADIO	Radio

PWR	Seats, Door Locks, Rear Defog. Power Seat
ACC*	Recliner, Rear Window Wiper, Trunk Release.
WPR	Windshield WiperWxher
CIG LTR	Cigarette Lighter
*Circuit Breaker	