

Wiring Diagram Type 928 S Model 85

PAGE 1	LAMPS
PAGE 2	BODY
PAGE 3	INSTRUMENT CLUSTER + INDICATORS
PAGE 4	VENTILATION AND HEATING
PAGE 5	RADIO
PAGE 6	ABS, ALARM SYSTEM, TRAILER COUPLING
PAGE 7	ENGINE - DIGITAL ENGINE ELECTRONICS
PAGE 8	CENTRAL ELECTRICAL SYSTEM

Wiring Diagram Type 928 S Model 85



The wiring diagram comprises eight individual wiring diagrams and one legend. They are subdivided into coordinate fields.

Each individual wiring diagram comprises a part of the central electrical system within a dash-dot frame.

This part of the central electrical system shows all the lines and relays required for individual wiring diagram.

The ground-connecting points are designated with "MP" and their location is shown in a vehicle diagram.

The 10-pole plugs on central electrical system are new. They are clipped together from 3 parts.

Part 1, with the cast-on fastening pin, is the "initial element".

Part 2 is the "module element".

Both parts are identified by the digits 1 . . . 5.

Part 3 is a "coding element".

The designations of the plug connections in wiring diagram for central electrical system refer e. g. from A 11 . . . 15 to the "initial element", from A 21 . . . 26 to module element.



Printed in Germany - X, 1984


Wiring Diagram Type 928 S
Model 85 page 1

LAMPS

Wiring Diagram Type 928 S Model 85 page 1

Wiring 97

LAMPS



Printed in Germany - X, 1984

SW - BLACK WS - WHITE RT - RED GN - GREEN GE - YELLOW GR - GREY BR - BROWN BL - BLUE LI - VIOLET

Current Flow Diagram 97-215

Wiring Diagram Type 928 S Model 85 page 2

BODY

BODY

Wiring



SW = BLACK WS = WHITE RT = RED GN = GREEN GE = YELLOW GR = GREY BR = BROWN BL = BLUE LI = VIOLET

Current Flow Diagram 97-217


Wiring Diagram Type 928 S Model 85 page 3

INSTRUMENT CLUSTER + INDICATORS

Wiring Diagram Type 928 S Model 85 page 3

Wiring 97

INSTRUMENT CLUSTER + INDICATORS



Printed in Germany - X, 1984

SW - BLACK WS - WHITE RT - RED GN - GREEN GE - YELLOW GR - GREY BR - BROWN BL - BLUE II - VIOLET


Current Flow Diagram 97-219

Wiring Diagram Type 928 S Model 85 page 4

VENTILATION AND HEATING

VENTILATION AND HEATING

Wiring



SW - BLACK WS - WHITE RT - RED CN - GREEN GE - YELLOW GR - GREY BR - BROWN BL - BLUE LI - VIOLET

Current Flow Diagram 97-221


Wiring Diagram Type 928 S
Model 85 page 5

RADIO

Wiring Diagram Type 928 S Model 85 page 5

Wiring 97

RADIO



Printed in Germany - X, 1984

Current Flow Diagram 97-223


Wiring Diagram Type 928 S Model 85 page 6

ABS, ALARM SYSTEM, TRAILER COUPLING

Wiring Diagram Type 928 S Model 85 page 6

ABS, ALARM SYSTEM, TRAILER COUPLING

Wiring 97



Printed in Germany - X, 1984

SW - BLACK WS - WHITE RT - RED GN - GREEN GE - YELLOW GR - GREY BR - BROWN BL - BLUE LI - VIOLET

Current Flow Diagram 97-225


Wiring Diagram Type 928 S Model 85 page 7

ENGINE - DIGITAL ENGINE ELECTRONICS

Wiring Diagram Type 928 S Model 85 page 7

Wiring 97

ENGINE - DIGITAL ENGINE ELECTRONICS



Printed in Germany - X, 1984

SW - BLACK WS - WHITE RT - RED GN - GREEN GE - YELLOW GR - GREY BR - BROWN BL - BLUE LI - VIOLET

Current Flow Diagram 97-227


Wiring Diagram Type 928 S Model 85 page 8

CENTRAL ELECTRICAL SYSTEM

Wiring Diagram Type 928 S Model 85 page 8

Wiring 97

CENTRAL ELECTRICAL SYSTEM



Printed in Germany - X, 1984

SW - BLACK WS - WHITE RT - RED GN - GREEN GE - YELLOW GR - GREY BR - BROWN BL - BLUE LI - VIOLET

Current Flow Diagram 97-229