


# Pontiac Firebird 1997 fuse box diagram

## Instrument Panel Fuse Block



Pontiac Firebird – fuse box – instrument panel

| Fuses       | Usage                                                                                                                                                                                                  |
|-------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| STOP/HAZARD | Hazard Flashers, Brake Switch Assembly                                                                                                                                                                 |
| TURN B/U    | Traction Control/Second Gear Start Switch, Back/Up Lamp Switch, Turn Flasher, Daytime Running Lamps (DRL) Module                                                                                       |
| PCM BATT    | Powertrain Control Module (PCM), Fuel Pump Relay                                                                                                                                                       |
| RADIO ACCY  | Delco Monsoon Radio Amplifier, Power Antenna, Remote CD Player (trunk)                                                                                                                                 |
| TAIL LPS    | Daytime Running Lamps (DRL) Module, Headlamp Switch                                                                                                                                                    |
| HVAC        | HVAC Selector Switch, Rear Defogger Switch/Timer                                                                                                                                                       |
| PWR ACCY    | Parking Lamp Relay, Hatch Release Relay, Power Mirror Switch, Radio, Shock Sensor, Instrument Cluster                                                                                                  |
| COURTESY    | Body Control Module (BCM)                                                                                                                                                                              |
| GAUGES      | Body Control Module (BCM), Brake Switch Assembly (BTSI), Instrument Cluster, Daytime Running Lamps (DRL) Module                                                                                        |
| AIR BAG     | Diagnostic Energy Reserve Module (DERM), Dual Pole Arming Sensor                                                                                                                                       |
| CIG/ACCY    | Cigarette Lighter, Data Link Connector (DLC), Auxiliary Accessory Wire                                                                                                                                 |
| DEFOG/SEATS | Rear Defogger Switch/Timer, Rear Defogger Timer/Relay, Power Seats                                                                                                                                     |
| PCM IGN     | Powertrain Control Module (PCM), EVAP Canister Purge Vacuum Switch, EVAP Ca                                                                                                                            |
| WIPER/WASH  | Wiper Motor Assembly, Wiper/Washer Switch                                                                                                                                                              |
| WINDOWS     | Power Windows Switch (RH, LH), Express-Down Module, Coolant Level Latching Module, Convertible Top Switch                                                                                              |
| IP DIMMER   | Door Illumination Lamp (RH, LH), Headlamp Switch, Fog Lamp Switch, Instrument Cluster, HVAC Control Assembly, PRNDL Illumination Lamp, Ashtray Lamp, Radio, Steering Wheel Controls-Radio, Rear Window |

|       |                                                                                |
|-------|--------------------------------------------------------------------------------|
|       | Defogger Switch/Timer, Traction Control Switch (TCS) and 2nd Gear Start Switch |
| RADIO | Body Control Module (BCM), Radio, Amplifier, Steering Wheel Controls-Radio     |

## Underhood Electrical Center



Pontiac Firebird – fuse box – engine compartment

| Fuse        | Ampere rating [A] | Usage                                                                                                                     |
|-------------|-------------------|---------------------------------------------------------------------------------------------------------------------------|
| ABS IGN     | 5                 | Anti-Lock Brake System                                                                                                    |
| ACTUATORS   | 15                | Daytime Running Lamp Module, Headlamp Switch, Cooling Fan Relay, Exhaust, Gas Recirculation, EVAP Canister Purge Solenoid |
| R HDLP DR   | 15                | Headlamp Door Module                                                                                                      |
| L HDLP DR   | 15                | Headlamp Door Module                                                                                                      |
| ABS VLV     | 20                | Brake Pressure Valve                                                                                                      |
| ABS BAT     | 5                 | Electronic Brake Control Module                                                                                           |
| AIR PUMPFAN | 25                | AIR Pump (V8) Relay, Pump, Bleed Valve and Cooling Fan                                                                    |
| HORN        | 20                | Horn Relay                                                                                                                |
| INJECTOR    | 15                | Fuel Injectors                                                                                                            |
| ENG SEN     | 20                | Mass Airflow, Heated Oxygen Sensor, Reverse Lockout Solenoid, Skip Shift Solenoid, Automatic Transmission, Brake Switch   |
| IGNITION    | 10                | V6 VIN K: Electronic Ignition Module VS VIN P: Ignition Coil Module, Crankshaft Position Sensor                           |
| A/C-CRUISE  | 15                | Air Conditioning Compressor Relay; Cruise Control Switches and Modu                                                       |

| Relay | Usage                                               |
|-------|-----------------------------------------------------|
| B     | Air Conditioning Compressor                         |
| C     | Anti-Lock Brake SystedTraction Control System (TCS) |
| D     | Cooling Fan 1                                       |
| E     | AIR Pump                                            |
| F     | Cooling Fan 2                                       |
| G     | Not Used                                            |
| H     | Fog Lamps                                           |

|   |               |
|---|---------------|
| J | Cooling Fan 3 |
|---|---------------|