


Fiat Fiorino (Fiat Qubo) (from 2007) fuse box diagrams

Year of production: 2007, 2008, 2009, 2010, 2011, 2012, 2013, 2014, 2015, 2016

Fuse box in engine compartment



Fiat Fiorino – fuse box – engine compartment

Device protected	Fuse	Ampere rating [A]
Computer Body	F01	60
Available	F02	—
Starter system	F03	20
ABS (pump)	F04	40
Available	F05	—
One-speed engine cooling electric fan (75W)/ Low speed engine cooling electric fan (187W)	F06	20
Low speed engine cooling electric fan (350W)	F06	30
High speed engine cooling electric fan (187W)	F07	30
High speed engine cooling electric fan (350W)	F07	40
Climate system electric fan	F08	30
Available (trailer kit)	(F09)	(15)
Buzzers	F10	10
Engine control system (secondary loads)	F11	10
Main beam headlights	F14	15
Available	F15	—
+15 Engine control unit/Relay reel T20	F16	7,5
Engine control unit (1.4 version)	F17	10
Engine control unit (1.3 Multijet version)	F17	10
Relay reel T09 (version 1.4)	F18	7,5
Engine control unit/Relay reel T09 (1.3 Multijet version)	F18	7,5
Climate system compressor	F19	7,5
Rear heated window/Mirror demisters	F20	30
Fuel pump	F21	15
Engine control unit (1.3 Multijet version)	F22	15

INT Sound system node/Bluetooth central unit node/Blue&Me node/ Movement of electric door mirrors/Clutch switch/Stop light control (NC)	F51	5
Instrument panel node	F53	5
Door mirror defrosters	F41	7,5
Available	F45	—
Available	F46	—
Available	F90	—
Available	F91	—
Available	F92	—
Available	F93	—
Cigar lighter / Passenger compartment current outlet	F94	15
Available	F95	—
Cigar lighter / Passenger compartment current outlet	F96	15
Front seat heater (on driver's side)	F97	10
Front seat heater (on passenger's side)	F98	10

WARNING: Terminal and harness assignments for individual connectors will vary depending on vehicle equipment level, model, and market.