

66 53 Reversing camera E84

IMPORTANT! When setting the correct hole distance, it is important that you follow the repair instructions for calibrating the reversing camera!		
Settings	Hole	8
Longitudinal rod (A)		
Transverse rod (B)	mm	150
(Beissbarth and Hunter rapid clamping holder)		
Transverse rod (B)	mm	55
(CORGHI rapid clamping holder)		