
Cigarette Lighter and Power Outlet – 12V (Double Cab)



: Parts Location

Code	See Page	Code		See Page	Code		See Page
C7	72	J52	B	74	P7	A	75
F13	70	P6	B	75		B	75
J45	74		C	75	P24		75

: Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
1E	49	Cowl Wire and Driver Side J/B (Lower Finish Panel)
1G		
1H		
1L	49	Engine Room Main Wire and Driver Side J/B (Lower Finish Panel)

: Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
ID2	92	Cigarette Lighter Wire and Cowl Wire (Instrument Panel Brace LH)
IM1	92	Console Box Wire and Cowl Wire (Rear Console)

: Ground Points

Code	See Page	Ground Points Location
IN	92	Right Kick Panel
IO	92	Left Kick Panel