



F RELAY LOCATIONS


[Engine Compartment]




[Body]



[Instrument Panel] (LHD)



(RHD)




F RELAY LOCATIONS

② : Engine Room R/B and J/B


Front Side of Left Suspension Tower
(See Page 20)

* 1:30A HEAD LP CLN
* 2:HEAD LH UPR
* 3:15A IG2 (1AZ-FE)
30A FUEL HTR (1CD-FTV)




cardiagn.com

⑦ : Engine Room R/B No.2 **Front Side of Left Suspension Tower**
(See Page 20)



⑤ : Engine Room R/B No.4 **Left Side of Air Cleaner** (See Page 20)





F RELAY LOCATIONS

○ : Instrument Panel J/B

LHD : Lower Finish Panel (See Page 21)


RHD : Left Side of Grove Box (See Page 21)






F RELAY LOCATIONS

[Instrument Panel J/B Inner Circuit]



cardiagn.com

(Cont'd)





F RELAY LOCATIONS


○ : Center J/B

LHD : Right Side of Grove Box (See Page 21)

RHD : Lower Finish Panel (See Page 21)




[Center J/B Inner Circuit]



F RELAY LOCATIONS

○ : Center J/B No.2

Near the Steering Column (See Page 21)



[Center J/B No.2 Inner Circuit]

