


Dodge Monaco 1974 – 1976 fuse box diagram

Fuse box diagram



Dodge Monaco – fuse box diagram

Fuse	[A]	Protected Component
1	5	Radio
2	20	Air conditioner compressor clutch, rear window defogger, cornering lights (Monaco only), speed control, automatic temperature control relay
3	20	Turn signal flasher circuit, back-up lights, voltage limiter, fuel gauge, oil gauge, temperature gauge
4	20	Air conditioner blower motor relay, heater blower motor
5	30	Air conditioner high blower
6	5	Headlights and windshield wiper/washer switch light, instrument cluster lights (also in cavity 2), tailgate unlock switch light, radio light, rear window defogger, cigar lighter light, clock light, right ash tray light, (D-C only)

7	20	Clock, cigar lighter, tail light, side marker lights, park & turn signal lights, instrument cluster lights (also in cavity 1), license lights
8	20	Trunk light, ignition switch light & time delay relay, rear dome light (wagons only), hazard flasher circuit, stop light, seat belt, key-in headlights-on buzzer, map light, courtesy light, glove box light, dome light, seat belt light
9	20	Horns, horn relay
10	20	Power window relay, brake warning light, hot temperature indicator light (engine), door ajar indicator light, oil warning light, electric trunk, lid, seat belt interlock, ignition feed