

Buick Roadmaster 1994 fuse box diagram

Instrument Panel Fuse Block




Buick Roadmaster – fuse box – instrument panel

Fuse	Ampere rating [A]	Usage
6	15	Turn Signal Lamp Flasher, Park Neutral Position Switch
7	10	Electronic Brake Control Module
8	15	Wagon Rear Wiper
9	10	Radio
10	25	Windshield Wiper Washer Switch
11	10	Rear Defog Relay, SDM, Rear Compartment Lid Release Switch Headlamp Switch I/P Cluster, Rear Defog Switch
12	10	Auto Level Control Sensor, Ignition Switch
13	10	Inside Rearview Mirror, Warning Alarm, Cruise Control Release Switch, Headlamp Auto Control Module, Daytime Running Lamp Control Module, Remote Control Door Lock Receiver
14	10	Theft-Deterrent Module
15	15	Inflatable Restrain Diagnostic Energy Reserve Module
16	10	Cruise Control Module, Cruise Control Switch
17	20	Heater and A/C Control, Low Blower Module Relay
18	10	Power Steering Control Module
20	10	Electric Actuator, Vacuum Electric Solenoid, Heater and A/C Control, Instrument Cluster
24	10	SDM, Theft-Deterrent Relay
26	20	Radio Power Antenna Relay

27	10	Auto Level Control Sensor, Rear Compartment Courtesy Lamp, Mercury Switch
28	20	Cigarette Lighter
29	20	Remote Control Door Lock Receiver, Liftgate Wiper Latch Switch, Rear Glass Release Switch, Rear compartment Lid Release Switch
30	15	Radio
31	20	Headlamp Switch, Headlamp Auto Control Module, Daytime Running Lamps Control Module
32	25	Horn Relay
33	10	Warning Alarm, I/P Compartment Lamp Switch, I/P Cluster, Heater and A/C Control
34	10	Theft-Deterrent Module
35	15	Courtesy Lamp Relay, Front Door Lock Switch, Door Courtesy, Outside Remote Control Mirror, Visor Vanity Mirror
36	15	Rear Window Wiper, Deck Lid Pull Down Actuator
37	20	Stoplamp Switch, Hazard Lamp Flashe
40	30	Blower Motor Control Module
41	10	Turn Signal Switch, Side Marker Lamps, Turn Parking Lamps
42	10	Heater and A/C Control , Headlamp Switch, Instrument Cluster, Radio, Headlamp and Instrument Panel Lamp Dimmer Switch, Panel Lamps Dimming Module, Interior Lights
43	10	Opera Lamps, License Lamp, Marker Lamps, Tailamps, Tail/Turn Stoplamps
44	10	Heated Power Mirrors

Circuit Breaker	Ampere rating [A]	Usage
2	30	Master Power Window Switch, Power Window Lockout Switch, Power Window Control Module
3	30	Door Lock Relay, Power Seat Switch, Recline Switch, Passenger Seat Lumbar Controls
4	30	Rear Window Defog Switch, Rear Window Defog Relay

Engine Compartment Fuse Block



Buick Roadmaster – fuse box – engine

compartment

Fuse	Ampere rating [A]	Usage
1	25	Auto Level Control Air Compressor
2	15	Fuel Pump Relay, Fuel Pump Switch and Engine Oil Pressure Sensor, PCM
3	20	Secondary Air Pump Relay, Underhood Lamp
4	10	Mass Air Flow Sensor, Air Pump Relay, EGR Solenoid, Evaporative Emission Solenoid, Oxygen Sensor
5	10	PCM, Ignition Coil, Automatic Transmission
6	10	Fuel Injector Cylinders One, Four, Six, Seven
7	10	Primary Cooling Fan, A/C Compressor Relay
8	10	Generator, Secondary Cooling Fan
9	10	Fuel Injector Cylinders Two, Three, Five, Eight