

HVAC (Heating, Ventilation and Air Conditioning)

*: Read [SRS precautions](#) before working in this area

Special Tools	22-2	Face Panel/Button Replacement	22-56	Evaporator Temperature Sensor Test	22-63	A/C System Service Refrigerant Recovery ...	22-75
Component Location Index	22-3	Air Mix Control Motor Replacement	22-57	Power Transistor Test	22-63	Performance Test	22-76
Wiring/Connector Locations	22-5	Test	22-57	Relays Test	22-64	Pressure Test Chart	22-78
Description Outline	22-7	Mode Control Motor Replacement	22-58	Evaporator/Blower Unit Replacement	22-65	Evacuation	22-88
Fan Control Unit	22-8	Test	22-58	Overhaul	22-67	Charging	22-89
A/C Pressure Switch	22-9	Recirculation Control Motor Replacement	22-59	Dust and Pollen Filters Replacement	22-68	Leak Test	22-89
Evaporator Pressure Regulator (EPR)	22-10	Test	22-59	Heater Unit *Replacement	22-69	Compressor Replacement	22-79
Troubleshooting Symptom Chart	22-11	Replacement	22-59	Overhaul	22-71	Component Location Index	22-81
Self-diagnosis Function	22-12	In-car Temperature Sensor Replacement	22-60	Temperature Control Adjustment	22-72	Clutch Inspection	22-82
Climate Control Unit Input/Output Signals	22-13	Test	22-60	A/C Service Tips and Precautions	22-73	Clutch Overhaul	22-83
Climate Control Unit Replacement	22-55	Outside Air Temperature Sensor Replacement	22-61	A/C System Torque Specifications	22-74	Relief Valve Replacement	22-84
Bulb Replacement	22-55	Test	22-61			A/C Compressor Belt Adjustment	22-85
		Sunlight Sensor Replacement	22-62			Condenser Replacement	22-86
		Test	22-62				