

Body Electrical

*: Read [SRS precautions](#) before working in this area

Special Tools	23-2	HID Lamp System Troubleshooting		Window Antenna Wire		Immobilizer Receiver	
Troubleshooting		'99-04 Models	23-120	Test/Repair	23-155	Replacement	23-189
Tips and Precautions	23-3	Headlights		XM Radio ('04 Model)		Driving Position Memory System (DPMS)	
Five-step Troubleshooting ..	23-5	Replacement	23-121	Receiver Terminals	23-38c	Component Location	
Relay and Control Unit Locations		HID Bulb Removal		Antenna Terminals	23-42c	Index	23-190
Engine Compartment		'99-04 Models	23-122	Accessory Power Socket		Description	23-192
'96-01 Models	23-6	Adjustment		Replacement	23-156	Self Diagnostic	
'02-04 Models	23-2a	'96-98 Models	23-123	Cigarette Lighter		Procedures	23-200
Dashboard	23-8	'99-04 Models	23-124	Replacement	23-157	DTC Chart	23-201
Door, Floor, Roof and Rear		Taillights		Horns		Troubleshooting Guide	23-202
Bulkhead	23-10	Replacement	23-125	*Component Location		Pre-troubleshooting Tests ..	23-204
Under-dash Fuse/Relay Box		Fog lights		Index	23-158	Driving Position Memory	
Removal/Installation	23-66	Switch Test	23-126	Horn Test	23-161	Switch Test	23-225
Power Relays Test	23-67	Adjustment	23-127	Switch Test	23-162	Steering Column	
* Ignition Switch		Replacement	23-127	Seat Belt Tension Reducer		Switch Test	23-225
Test	23-70	License Plate Light		Test	23-166	Tilt/Extend-retract	
Electrical Switch		Replacement	23-128	Moonroof		Motor Test	23-226
Replacement	23-71	High Mount Brake Light		Component Location		Tilt/Extend-retract Position	
Battery Test	23-72	Replacement	23-131	Index	23-167	Sensor Test	23-226
Gauge Assembly		Turn Signal/Hazard Flasher System		Control Unit Input Test	23-169	Driver's Power Seat Switch	
Component Location		Component Location		Motor Test	23-172	Test	23-227
Index	23-74	Index	23-132	Switch Test	23-173	Driver's Power Seat Motor	
Gauge/Terminal Location Index		Turn Signal/Hazard Relay		Seat Heaters		Test	23-228
'96-03 Models	23-75	Input Test	23-134	Component Location		Driver's Power Seat Position	
'04 Model	23-27c	Hazard Warning Switch		Index	23-174	Sensor Test	23-229
Bulb Locations	23-76	Test	23-135	System Description	23-174	Steering Column Control Unit	
Maintenance Reminder		Interior Lights		Switch Test/Replacement ..	23-176	Input Test	23-230
Light	23-76	Component Location		Heater Test	23-176	Power Seat Control Unit	
Select/Reset Switch Test	23-84	Index	23-136	Automatic Inside Dimming Mirror		Input Test	23-234
Outside Air Temperature Indicator		Trunk Light Test	23-139	Component Location		Power Mirror Control Unit	
Troubleshooting	23-84	Glove Box Light Test	23-139	Index	23-177	Input Test	23-238
Calibration	23-84	Vanity Mirror Light Test	23-140	Description		Multiplex Control System	
Replacement	23-85	Clock		'96-01 Models	23-177	Component Locations	23-241
Vehicle Speed Sensor (VSS)		Removal	23-141	'02-04 Models	23-45a	System Description	23-241
Replacement	23-85	Terminals	23-141	Test/Replacement		System Functions	23-243
Troubleshooting	23-86	Stereo Sound System		'96-01 Models	23-178	Multiplex Communication	
Safety Indicator		*Component Location Index		'02-04 Models	23-47a	System	23-243
Component Location Index .	23-88	'96-03 Models	23-142	Front Passenger's Power Seat		Troubleshooting Guide	23-244
Indicator Input Test	23-94	'04 Model	23-35c	Component Location		Power and Ground Test	23-245
Brake Light Failure Sensor		Stereo Amplifier Terminals		Index	23-179	Self Diagnosis Function	
Test	23-96	(with Bose Sound System)		Switch Test/Replacement ..	23-181	(Mode 1)	23-248
Lighting System		'96-03 Models	23-143	Motor Test	23-181	Wake-up Function Test	23-249
Component Location		'04 Model	23-36c	Immobilizer System		Confirming the Function	23-250
Index	23-98	Audio Unit Terminals		Component Location		Faulty Wake-up Line	
Automatic Lighting Control Unit		'96-01 Models	23-144	Index	23-182	Symptoms	23-251
Input Test (USA)	23-114	'02-03 Models	23-50a	Description	23-183	Check the Wake-up	
Daytime Running Lights Control		'04 Model	23-37c	Problems and Replacement		Function	23-251
Unit Input Test		*Audio Unit Removal	23-150	Parts	23-185	Self Diagnosis Function	
(Canada)	23-116	CD Changer Removal	23-152	Control Unit Input Test	23-187	(Mode 2)	23-252
Combination Light Switch		Stereo Amplifier Removal ...	23-152	Immobilizer Receiver and		Integrated Control	
Test	23-118	Speaker Replacement	23-153	Transponder Test	23-188	Ignition Key Light	
Replacement	23-121	Radio Remote Switch Test ..	23-154			Replacement	23-254

Body Electrical (Cont'd)

Dash Lights Brightness Control	
Controller Test/	
Replacement	23-256
Entry Light Control System	
Component Location	
Index	23-257
Control Unit Input Test	23-259
Front Ceiling Light Test	23-262
Rear Ceiling Light Test	23-262
Courtesy Light	
Replacement	23-263
Ignition Key Switch Test	23-263
Door Switch Test	23-264
Rear Window Defogger	
*Component Location	
Index	23-265
Control Unit Input Test	23-267
Door Switch Test	23-269
Defogger Coil Test	23-269
Function Test	23-270
Defogger Wire Repair	23-270
Trunk Lid Opener	
Component Location	
Index	23-271
Control Unit Input Test	23-273
Main Switch Test	23-274
Switch Test	23-274
Solenoid Test	23-275
Power Door Locks	
Component Location	
Index	
'96-01 Models	23-276
'02-04 Models	23-26a
Transmitter Test	
'96-01 Models	23-282
'02-04 Models	23-34a
Troubleshooting	23-283
Control Unit Input Test	23-284
Keyless Receiver Unit Input Test	
'96-01 Models	23-290
'02-04 Models	23-32a
Keyless Transmitter Codes	
Input Procedure	
'96-01 Models	23-292
'02-04 Models	23-34a
Driver's Door Lock Actuator	
Test	23-293

Front Passenger's Door Lock	
Actuator Test	23-293
Rear Door Lock Actuator	
Test	23-294
Driver's Door Key Cylinder	
Switch Test	23-295
Door Lock Switch Test	23-295
Power Windows	
Component Location	
Index	23-296
Description	
'96-01 Models	23-297
'02-04 Model	23-40a
Troubleshooting	23-310
Control Unit Input Test	
'96-01 Models	23-311
'02-04 Model	23-42a
Master Switch	
Replacement	23-316
Passenger's Window	
Switch Replacement	23-316
Passenger's Window	
Switch Test	23-317
Passenger's Window	
Motor Test	23-317
Driver's Window Motor Test	
'96-01 Models	23-318
'02-04 Models	23-41a
Driver's Window Switch Test	
'02-04 Models	23-44a
Wiper/Washers	
Component Location	
Index	23-319
Troubleshooting	23-324
Control Unit Input Test	23-325
Wiper/Washer Switch	
Test	23-327
Windshield Wiper Motor	
Test	23-328
Washer Motor Test	23-328
Switch Replacement	23-329

Security Alarm System	
Component Location	
Index	23-330
Description	23-332
Control Unit Input Test	23-346
Indicator Replacement	23-352
Hood Switch Test	23-352
Trunk Lid Latch Switch	
Test	23-353
Trunk Key Cylinder Switch	
Test	23-353
Power Mirrors	
Component Location	
Index	23-354
Function Test	
(without memory)	23-357
Switch Test	23-358
Power Mirror Test	23-359
Power Mirror Actuator	
Replacement	23-360
Homelink Remote Control System	
Test	23-361
Navigation System	
Special Tools	23-364
Component Location Index	
'96-03 Models	23-365
'04 Model	23-3d
Description ('96-'03 Models)	
Overview	23-366
Navigation Function	23-367
Description ('04 Model)	
Overview	23-14d
Navigation Function	23-16d
General Troubleshooting	
Information ('04 Model) ..	23-4d
Control Unit Terminal Arrangement	
'96-99 Models	23-376
'00-03 Models	23-379
'04 Model	23-7d
Troubleshooting	
Precautions	23-383
Troubleshooting Guide	
'96-03 Models	23-385
'04 Model	23-6d

System Diagnosis Mode	
('04 Model)	23-40d
Picture Diagnosis	
'96-99 Models	23-386
'00-03 Models	23-392
Forced Starting of Display	
'96-03 Models	23-412
'04 Model	23-52d
Hard Disc ('96-99 Models)	
Replacement	23-413
DVD-ROM Replacement	
'00-03 Models	23-413
'04 Model	23-52d
Navigation Unit/GPS Antenna	
Removal/Installation	
'96-03 Models	23-414
'04 Model	23-53d
Display Unit Removal/Installation	
'96-03 Models	23-415
'04 Model	23-54d
Clock Display Size and Location	
Adjustment	
('00-03 models only)	23-417
Voice Control Switch	
Removal/Installation	23-54d
OnStar System ('02-04 Models)	
Component Location Index	
'02-03 Models	23-52a
'04 Model	23-43c
Description	23-53a
Troubleshooting	23-58a
Control Unit Input Test	23-59a
Interface Unit Input Test	
'02-03 Models	23-62a
'04 Model	23-46c
Radio Frequency Modulator	
Input Test	23-64a
Buttons and Microphone Input Test	
'02-03 Models	23-66a
'04 Model	23-48c
Cellular Phone Antenna Replacement	
'02-03 Models	23-67a
'04 Model	23-49c
Lumbar Support System ('04 Model)	
Component Location	
Index	23-50c
Switch Test	23-52c
Motor Test	23-52c