


Troubleshooting


If the charging system light does not come on or does not go off, or the battery is dead or low, test the following items in the order listed below:

1. Battery (see [section 23](#))
2. Charging System Light (see below)
3. Alternator/Regulator (see page [4-27](#))

Charging System Light Test




ALTERNATOR
4P CONNECTOR



Wire side of female terminals

L
(WHT/BLU)



L
(WHT/BLU)



(cont'd)

Charging System

Troubleshooting (cont'd)

(From page 4-25)

