


Engine Oil

Replacement

CAUTION: Remove the drain bolt carefully while the engine is hot; the hot oil may cause scalding.

1. Warm up the engine.
2. Drain the engine oil.




3. Reinstall the drain bolt with a new washer, and refill with the recommended oil.

Requirement	API Service Grade: Use "Energy Conserving" SJ or "Energy Conserving II" SH grade oil. SAE 5 W - 30 preferred. You can also use an oil that bears the API CERTIFICATION mark.
Capacity	4.3 ℓ (4.5 US qt, 3.8 Imp qt) at oil change. 4.6 ℓ (4.9 US qt, 4.0 Imp qt) at oil change including filter. 5.3 ℓ (5.6 US qt, 4.7 Imp qt) after engine overhaul.
Change interval	Every 7,500 miles (12,000 km) or 12 months (Normal conditions). Every 3,750 miles (6,000 km) or 6 months (Severe conditions).

NOTE: Under normal conditions, the oil filter should be replaced at every other oil change. Under severe conditions, the oil filter should be replaced at each oil change.




The numbers in the middle of the API Service label tell you the oil's SAE viscosity or weight. Select the oil for your vehicle according to this chart:



An oil with a viscosity of 5W - 30 is preferred for improved fuel economy and year-round protection in the vehicle. You may use a 10W - 30 oil if the climate in your area is limited to the temperature range shown on the chart.



API CERTIFICATION MARK



API SERVICE LABEL

4. Run the engine for more than 3 minutes, then check for oil leakage.