


Wheel Sensor Replacement

Install the sensors carefully to avoid twisting wires.

Front



Rear

