



Audio driving instructions cannot be heard




(To page 23-410)

NAVIGATION UNIT CONNECTOR B (16P)




Wire side of female terminals

NAVIGATION UNIT CONNECTOR B (16P)



Wire side of female terminals

NAVIGATION UNIT CONNECTOR B (16P)




Wire side of female terminals

(cont'd)


Troubleshooting

'00 - 01 Models (cont'd)


(From page 23-409)




NAVIGATION UNIT CONNECTOR B (16P)




NAVIGATION UNIT CONNECTOR B (16P)




NAVIGATION UNIT CONNECTOR A (12P)




NAVIGATION UNIT CONNECTOR A (12P)



(From page 23-410)



NAVIGATION UNIT CONNECTOR A (12P)



Wire side of female terminals