


# Isuzu Trooper 1995 – 1996 fuse box diagram

## Fuse box diagram




Isuzu Trooper – fuse box diagram

| Number | Fuse name               | A  | Function                  |
|--------|-------------------------|----|---------------------------|
| F-1    | —                       | —  | —                         |
| F-2    | O 2<br>SENSOR<br>HEATER | 10 | Engine control            |
| F-3    | HORN<br>HAZARD          | 15 | Hams; Hazard light        |
| F-4    | H/LAMP-LH               | 15 | Headlights and fog lights |
| F-5    | H/LAMP-R<br>H           | 15 | Headlights                |
| F-6    | —                       | —  | —                         |

|      |            |    |                                                                          |
|------|------------|----|--------------------------------------------------------------------------|
| F-7  | —          | —  | —                                                                        |
| F-8  | (FRT. FOG) | 15 | Fog lights                                                               |
| F-9  | ABS        | 20 | Rear wheel anti-lock (RWAL) brake system or anti-lock brake system (ASS) |
| F-10 | FUEL PUMP  | 15 | Engine control                                                           |
| F-11 | —          | —  | —                                                                        |
| F-12 | TAIL       | 15 | Taillights                                                               |

| Fusible Link Number | Fusible Link Name | A  | Circuit Protected      |
|---------------------|-------------------|----|------------------------|
| FL-1                | MAIN              | 80 | See Power Distribution |
| FL-2                | KEY SW            | 50 | See Power Distribution |
| FL-3                | ECM               | 30 | Engine control         |
| FL-4                | —                 | —  | —                      |
| FL-5                | —                 | —  | —                      |

|      |                          |    |                               |
|------|--------------------------|----|-------------------------------|
| FL-6 | (ABS<br>4/WHEEL<br>ONLY) | 40 | Anti-lock brake system, (ABS) |
|------|--------------------------|----|-------------------------------|



Isuzu Trooper – fuse box diagram

| Number | Fuse name     | A  | Function                                                                                                                                                         |
|--------|---------------|----|------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| C-1    | STARTER RELAY | 10 | Starting system; blower contrors; A/C Compressor controls; supplemental restraint system (SRS)                                                                   |
| C-2    | (SEAT HEATER) | 15 | Seat heater                                                                                                                                                      |
| C-3    | TRUNK BACK    | 15 | Back up lights; tum lights; hazard lights: cornering lights; A/T shift indicator                                                                                 |
| C-4    | ELEC. IGN.    | 10 | Rear defogger; cruise control; power windows: engine control; door mirror defoggers; shift interlock system; power sunroof; 4-wheel anti-lock brake system (ABS) |

|      |                      |    |                                                                                                                |
|------|----------------------|----|----------------------------------------------------------------------------------------------------------------|
| C-5  | FRT WIPER & WASHER   | 15 | Windshield wiper/washer                                                                                        |
| C-6  | RR WIPER & WASHER    | 10 | Rear wiper/washer                                                                                              |
| C-7  | (H/LAMP WIPER)       | 10 | Headlight wiper/washer                                                                                         |
| C-8  | ENGINE               | 15 | Engine control; charging system                                                                                |
| C-9  | IGN. COIL            | 15 | Ignition system                                                                                                |
| C-10 | METER GAUGE          | 10 | Gauges; indicators                                                                                             |
| C-11 | (AUDIO [ACC]) MIRROR | 10 | Sound system; power mirrors; clock                                                                             |
| C-12 | CIGARETTE            | 20 | Cigarette lighter                                                                                              |
| C-13 | (ANTI THEFT)         | 10 | Anti-theft system                                                                                              |
| C-14 | STOP A/T CONT        | 15 | Brake lights; automatic transmission control; shift interlock system; rear wheel anti-lock (RWAL) brake system |
| C-15 | (AUDIO [B])          | 20 | Sound system                                                                                                   |

|      |                |    |                                                                                                       |
|------|----------------|----|-------------------------------------------------------------------------------------------------------|
| C-16 | CLOCK [B] ROOM | 10 | Sound system; interior lights; key-in ignition warning system; anti-theft system; auto antenna; clock |
| C-17 | RR DEFOG       | 25 | Rear defogger                                                                                         |
| C-18 | (DOOR LOCK)    | 20 | Power door locks; anti-theft system; power windows                                                    |
| C-19 | BLOWER         | 25 | Blower controls                                                                                       |
| C-20 | (AIR CON)      | 10 | A/C compressor controls                                                                               |
| C-21 | SRS-1          | 10 | Supplemental restraint system (SRS)                                                                   |
| C-22 | SRS-2          | 10 | Supplemental restraint system (SRS)                                                                   |
| C-23 | SRS-3          | 10 | Supplemental restraint system (SRS)                                                                   |
| C-24 | SRS-4          | 10 | Supplemental restraint system (SRS)                                                                   |

| Circuit Breaker Number | Circuit Breaker Name | A  | Circuit Protected                                           |
|------------------------|----------------------|----|-------------------------------------------------------------|
| C/B-1                  | —                    | —  | —                                                           |
| C/B-2                  | (P/W, P/S, S/R)      | 30 | Power windows: power sunroof; power seats; power door locks |