

3711 Overview of tightening torques

Front air suspension strut/spring strut on body		
M8 Renew screws.	Tightening torque	28Nm

3712 Overview of tightening torques

Active stabiliser to right-hand retaining bracket

M6	Tightening torque	8Nm
----	-------------------	-----

Active stabilizer wiring harness on right-hand retaining bracket

M6	Tightening torque	8Nm
----	-------------------	-----

Rear spring strut/air suspension strut to camber control arm

M14 Renew screw and nut.	Tightening torque	165Nm
	Angle of rotation	90°

Special tool for spring strut/air suspension strut

Clamp A for spring strut/air suspension strut	Tightening torque	40Nm
---	-------------------	------

Special tool to joint bush

Clamp B to joint bush	Tightening torque	40Nm
-----------------------	-------------------	------

Vehicle wiring harness of active stabilizer on rear axle support

M6	Tightening torque	8Nm
----	-------------------	-----

3713 Overview of tightening torques

Air line to air supply system		
	Tightening torque	2Nm
Air line to pressure accumulator		
	Tightening torque	5Nm
Air pipe to air suspension strut		
	Tightening torque	2,25Nm
Air pipe to air suspension strut		
	Tightening torque	2,25Nm

3714 Overview of tightening torques

Bracket, ride height sensor, to body		
M6	Tightening torque	8Nm
Jointed rod ride height sensor on wishbone		
M6	Tightening torque	8Nm
Ride height sensor to holder		
M5 Renew screw.	Tightening torque	4,5Nm
VDP control unit to body		
M6	Tightening torque	6Nm
Vertical acceleration sensor to swivel bearing		
M6 Renew screw.	Tightening torque	11,8Nm
Vertical acceleration sensor to wheel carrier		
M6 Renew screw.	Tightening torque	11,8Nm

3721 Overview of tightening torques

Pressure accumulator to vehicle underbody		
M6	Tightening torque	8Nm
Renew nut.		

3722 Overview of tightening torques

Air supply unit to body		
M6 Multi-purpose nut with paint scrape groove Renew nut.	Tightening torque	8Nm