


Chevrolet Malibu 1978- 1981 fuse box diagram

Fuse box diagram



Chevrolet Malibu – fuse box diagram

Fuse	[A]	Protected Component
1	5	Instrument panel lights, alarm buzzer, heater dial light
2	20	Choke heater
3	5	Instrument panel lights, heater dial lights
4	30	Circuit breaker: Power windows and sunroof
5	—	—
6	25	Heater and air conditioning
7	10	Electronic Control Module
8	—	—
9	25	Windshield wipers
10	20	Stop, hazard, courtesy, dome, glove box and engine compartment light
11	10	Cruise control, rear window defogger, gauges, closed loop, warning lamps and buzzers and tailgate unlock.
12	20	Parking, side marker, license and tail lights
	10	Warning lamps and buzzers, trunk release, torque converter clutch, vehicle speed sensor, rear window defogger

13	10	Radio, idle stop solenoid, delay wipers, cruise control
14	30	Circuit breaker: Power door locks, power seats, rear window defogger and tailgate lock
15	20	Back-up and turn signal lights
	20	Parking, side marker, license and tail lights
16	20	Luggage compartment light, cigar lighter, clock, courtesy lights, key warning buzzer, closed loop, dome and reading lights, power antenna, horns
17	—	—
18	20	Turn signal and back-up lights
19	—	—

Circuit Breaker:

- Headlights — Circuit breaker is integral with headlight switch to protect headlight circuit.
- Windshield Wiper — Circuit breaker integral with windshield wiper switch to protect wiper circuit.
- Power Seats, Power Windows & Power Door Locks — Circuit breaker is located on fuse panel to protect power accessories.
- Rear Window Defogger – Circuit breaker is located on left side fender inner skirt.