

Door Cord

WIRING SYSTEM

60.Door Cord


A: LOCATION

Connector				Connecting to	
No.	Pole	Color	Area	No.	Description
D2	2	★	C-4		Front door speaker LH
D3	6	★	B-2		Front power window motor RH
D4	2	Black	C-3		Front door tweeter LH
D5	6	★	C-3		Outer mirror assembly LH (without mirror heater)
	8	★	C-3		Outer mirror assembly LH (with mirror heater)
D7	16	★	B-4		Power window main switch
D10	2	★	C-4		Step light LH
D12	2	★	B-2		Front door speaker RH
D13	6	★	C-4		Front power window motor LH
D14	2	Black	B-2		Front door tweeter RH
D15	6	★	B-2		Outer mirror assembly RH (without mirror heater)
	8	★	B-2		Outer mirror assembly RH (with mirror heater)
D17	8	★	B-2		Front power window sub-switch
D18	2	★	C-4		Front door lock actuator LH
D20	2	★	B-3		Step light RH
D22	8	★	C-4	R10	Rear wiring harness
D23	2	★	C-4		Rear door speaker LH
D24	6	★	B-4		Rear power window motor LH
D25	8	★	B-4		Rear power window sub-switch LH
D26	2	★	B-5		Rear door lock actuator LH
D28	8	★	B-3	R13	Rear wiring harness
D29	2	★	B-3		Rear door speaker RH
D30	6	★	B-3		Rear power window motor RH
D31	8	★	B-3		Rear power window sub-switch RH
D32	2	★	B-3		Rear door lock actuator RH
D72	2	★	B-3		Front door lock actuator RH
D83	28	★	B-2	i101	Instrument panel wiring harness
D84	25	★	C-3	i76	
D102	3	★	C-4		Power window main switch
D125	5	★	B-2		Passenger's seat door lock switch

★ : White or natural color

Door Cord

WIRING SYSTEM



WI-19635