



# DIFFERENTIAL









## SST


|                                                                                     |             |                                      |                                                                                                                                                                   |
|-------------------------------------------------------------------------------------|-------------|--------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|    | 09213-58013 | Crankshaft Pulley Holding Tool       | FRONT DIFFERENTIAL CARRIER ASSEMBLY (4WD)                                                                                                                         |
|    | 09219-87202 | Engine Overhaul Stand                | FRONT DIFFERENTIAL CARRIER ASSEMBLY (4WD)<br>REAR DIFFERENTIAL CARRIER ASSEMBLY                                                                                   |
|    | 09219-87701 | Engine Overhaul Attachment           | FRONT DIFFERENTIAL CARRIER ASSEMBLY (4WD)                                                                                                                         |
|    | 09257-87202 | Crankshaft Bearing Replacer          | FRONT DIFFERENTIAL CARRIER ASSEMBLY (4WD)                                                                                                                         |
|    | 09308-00010 | Oil Seal Puller                      | FRONT DIFFERENTIAL CARRIER ASSEMBLY (4WD)                                                                                                                         |
|  | 09308-10010 | Oil Seal Puller                      | FRONT DIFFERENTIAL CARRIER OIL SEAL(4WD)<br>FRONT DIFFERENTIAL CARRIER ASSEMBLY (4WD)<br>REAR DIFFERENTIAL CARRIER OIL SEAL<br>REAR DIFFERENTIAL CARRIER ASSEMBLY |
|  | 09309-87201 | Transmission Bearing Replacer        | FRONT DIFFERENTIAL CARRIER ASSEMBLY (4WD)                                                                                                                         |
|  | 09310-87301 | Counter Shaft Front Bearing Replacer | REAR DIFFERENTIAL CARRIER ASSEMBLY                                                                                                                                |
|  | 09330-00021 | Companion Flange Holding Tool        | FRONT DIFFERENTIAL CARRIER ASSEMBLY (4WD)                                                                                                                         |
|  | 09350-87202 | Automatic Transmission Tool Set      | FRONT DIFFERENTIAL CARRIER ASSEMBLY (4WD)                                                                                                                         |

PP




PP

|                                                                                     |             |                                                  |                                                                                        |
|-------------------------------------------------------------------------------------|-------------|--------------------------------------------------|----------------------------------------------------------------------------------------|
|    | 09504-87501 | Differential Side Bearing Adjusting Nut Wrench   | REAR DIFFERENTIAL CARRIER ASSEMBLY                                                     |
|    | 09510-87301 | Front Hub & Drum Puller                          | FRONT DIFFERENTIAL CARRIER ASSEMBLY (4WD)                                              |
|    | 09515-87302 | Rear Hub Bearing Replacer                        | REAR DIFFERENTIAL CARRIER ASSEMBLY                                                     |
|    | 09530-87504 | Differential Drive Pinion Adjust Gauge Set       | FRONT DIFFERENTIAL CARRIER ASSEMBLY (4WD)                                              |
|    | 09548-87202 | Differential Overhaul Attachment                 | REAR DIFFERENTIAL CARRIER ASSEMBLY                                                     |
|    | 09564-97401 | Starting Torque Measurement Tool                 | REAR DIFFERENTIAL CARRIER ASSEMBLY                                                     |
|  | 09608-03071 | Replacer                                         | REAR DIFFERENTIAL CARRIER ASSEMBLY                                                     |
|  | 09608-87302 | Axle Hub Bearing & Drive Pinion Bearing Tool Set | REAR DIFFERENTIAL CARRIER ASSEMBLY                                                     |
|  | 09636-20010 | Upper Ball Joint Dust Cover Replacer             | FRONT DIFFERENTIAL CARRIER OIL SEAL (4WD)<br>FRONT DIFFERENTIAL CARRIER ASSEMBLY (4WD) |
|  | 09707-87302 | Spring Bush Remover & Replacer                   | REAR DIFFERENTIAL CARRIER ASSEMBLY                                                     |
|  | 09950-60010 | Replacer Set                                     | FRONT DIFFERENTIAL CARRIER ASSEMBLY (4WD)                                              |
|                                                                                     | 09950-97201 | Universal Puller                                 | REAR DIFFERENTIAL CARRIER ASSEMBLY                                                     |

|                                                                                   |             |                                  |                                                                                                                       |
|-----------------------------------------------------------------------------------|-------------|----------------------------------|-----------------------------------------------------------------------------------------------------------------------|
|  | O9213-31021 | Crankshaft Pulley Adjust Puller  | REAR DIFFERENTIAL CARRIER ASSEMBLY                                                                                    |
|  | O9330-87301 | Drive Pinion Flange Holding Tool | FRONT DIFFERENTIAL CARRIER ASSEMBLY (4WD)<br>REAR DIFFERENTIAL CARRIER OIL SEAL<br>REAR DIFFERENTIAL CARRIER ASSEMBLY |
|  | O9502-10012 | Differential Side Bearing Puller | FRONT DIFFERENTIAL CARRIER ASSEMBLY (4WD)                                                                             |

PP

## Introduction

|                                                                                     |            |                                                                      |                                                                                                                                                                                        |
|-------------------------------------------------------------------------------------|------------|----------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                                                     |            | Bearing Pillaring Attachment NO.145                                  | FRONT DIFFERENTIAL CARRIER ASSEMBLY (4WD)<br>REAR DIFFERENTIAL CARRIER ASSEMBLY                                                                                                        |
|                                                                                     |            | Torque Wrench                                                        | DIFFERENTIAL OIL                                                                                                                                                                       |
|                                                                                     |            | Torque Wrench                                                        | DIFFERENTIAL OIL<br>FRONT DIFFERENTIAL CARRIER OIL SEAL (4WD)<br>FRONT DIFFERENTIAL CARRIER ASSEMBLY (4WD)<br>REAR DIFFERENTIAL CARRIER OIL SEAL<br>REAR DIFFERENTIAL CARRIER ASSEMBLY |
|                                                                                     |            | Dial Indicator                                                       | REAR DIFFERENTIAL CARRIER ASSEMBLY                                                                                                                                                     |
|  |            | Preset Torque Wrench (20-100N*m)<br>(Parts Number : CL100N - 15D-MH) | DIFFERENTIAL OIL                                                                                                                                                                       |
|  | RH15DX24   | Ring Head (24mm)                                                     | DIFFERENTIAL OIL                                                                                                                                                                       |
|  | HMJ-450TWS | High-mission Jack<br>(Allowance load 450 Kg)                         | FRONT DIFFERENTIAL CARRIER ASSEMBLY (4WD)<br>REAR DIFFERENTIAL CARRIER ASSEMBLY                                                                                                        |

## Lubricant and others

|  |  |           |                                           |
|--|--|-----------|-------------------------------------------|
|  |  | MP Grease | FRONT DIFFERENTIAL CARRIER OIL SEAL (4WD) |
|--|--|-----------|-------------------------------------------|

|  |  |                                                           |                                                                                                                             |
|--|--|-----------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------|
|  |  | Limited Slip Differential Gear Oil (API GL-5, SAE 80W-90) | FRONT DIFFERENTIAL CARRIER OIL SEAL(4WD)<br>FRONT DIFFERENTIAL CARRIER ASSEMBLY (4WD)<br>REAR DIFFERENTIAL CARRIER ASSEMBLY |
|  |  | Red Lead Primer                                           | REAR DIFFERENTIAL CARRIER ASSEMBLY                                                                                          |
|  |  | Three Bond 1216                                           | FRONT DIFFERENTIAL CARRIER ASSEMBLY (4WD)                                                                                   |

PP

