


# Chevrolet Tahoe 2003 fuse box diagram

## Instrument panel fuse block

The fuse block access door is on the driver's side edge of the instrument panel.




Chevrolet Tahoe – fuse box – instrument panel

| Fuses          | Usage                                                               |
|----------------|---------------------------------------------------------------------|
| RR Wiper       | Rear Window Wiper Switch                                            |
| SEO ACCY       | Special Equipment Option Accessory                                  |
| WS WPR         | Windshield Wipers                                                   |
| TBC ACCY       | Truck Body Controller Accessory                                     |
| IGN 3          | Ignition, Heated Seats                                              |
| 4WD            | Four-wheel Drive System, Auxiliary Battery                          |
| HTR A/C        | Climate Control System                                              |
| LOCK           | Power Door Lock Relay (Lock Function)                               |
| HVAC 1         | Inside Rearview Mirror, Climate Control System                      |
| L DOOR         | Driver's Door Harness Connection                                    |
| CRUISE         | CRUISE Control                                                      |
| UNLOCK         | Power Door Lock Relay (Unlock Function)                             |
| RR FOG LP      | Rear Fog Lamp (Export Only)                                         |
| BRAKE          | Anti-Lock Brake System                                              |
| DRIVER UNLOCK  | Power Door Lock Relay (Drive's Door Unlock Function)                |
| IGN 0          | PCM, TCM                                                            |
| TBC IGN 0      | Truck Body Controller                                               |
| VEH CHMSL      | Vehicle and Trailer High Mounted Stoplamp                           |
| LT TRLR ST/TRN | Left Turn Signal/Stop Trailer                                       |
| LT TRN         | Left Turn Signals and Sidemarkers                                   |
| VEH STOP       | Vehicle Stoplamps, Brake Module, Electronic Throttle Control Module |
| RT TRLR ST/TRN | Right Turn Signal/Stop Trailer                                      |
| RT TRN         | Right Turn Signals and Sidemarkers                                  |

|             |                                   |
|-------------|-----------------------------------|
| BODY        | Harness Connector                 |
| DDM         | Driver Door Module                |
| AUX PWR 2   | Rear Cargo Area Power Outlet      |
| LOCKS       | Power Door Lock System            |
| TBC 2C      | Truck Body Controller             |
| FLASH       | Flasher Module                    |
| CB LT DOORS | Left Power Window Circuit Breaker |
| TBC 2B      | Truck Body Controller             |
| TBC 2A      | Truck Body Controller             |

## Center Instrument Panel Utility Block

The center instrument panel utility block is located underneath the instrument panel, to the left of the steering column.




Chevrolet Tahoe – fuse box – center

## instrument panel utility

| Device      | Usage                                            |
|-------------|--------------------------------------------------|
| SEO         | Special Equipment Option                         |
| TRAILER     | Trailer Brake Wiring                             |
| UPFIT       | Upfitter (Not Used)                              |
| SL RIDE     | Ride Control Harness Connection                  |
| HDLR 2      | Headliner Wiring Connector                       |
| BODY        | Body Wiring Connector                            |
| HDLNR 1     | Headliner Wiring Connector 1                     |
| SPARE RELAY | Not Used                                         |
| CB SEAT     | Driver and Passenger Seat Module Circuit Breaker |
| CB RT DOOR  | Right Power Window Circuit Breaker               |
| SPARE       | Not Used                                         |
| INFO        | Infotainment Harness Connection                  |

## Underhood Electrical Center

The underhood electrical center is located on the driver's side of the engine compartment near the battery.



Chevrolet Tahoe – fuse box – engine

compartment

\*1 – Gasoline Engine and Fuel Injection Rail #2

\*2 – Gasoline Engine and Fuel Injection Rail #1

\*3 – Gasoline Engine; Oxygen Sensor

\*4 – Gasoline Engine; Oxygen Sensor

\*5 – PCM Ignition

| Fuses     | Usage                                                                                                                |
|-----------|----------------------------------------------------------------------------------------------------------------------|
| GLOW PLUG | Not Used                                                                                                             |
| CUST FEED | Gasoline Accessow Power                                                                                              |
| STUD #1   | Auxiliary Power (Single Battery and Diesels Only)/Dual Battery (TP2) Do not install fuse.                            |
| MBEC      | Mid Bussed Electrical Center Power Feed, Front Seats, Right Doors                                                    |
| BLOWER    | Front Climate Control Fan                                                                                            |
| LBEC      | Left Bussed Electrical Center, Door Modules, Door Locks, Auxiliary Power Outlet-Rear Cargo Area and Instrument Panel |
| STUD 2    | Accessory Power/Trailer Wiring Brake Feed                                                                            |
| ABS       | Anti-Lock Brakes                                                                                                     |
| VSES/ECAS | Vehicle Stability                                                                                                    |
| IGN A     | Ignition Power                                                                                                       |
| IGN B     | Ignition Power                                                                                                       |
| LBEC 1    | Left Bussed Electrical Center, Left Door, Truck Body Controller, Flasher Module                                      |
| TRL PARK  | Parking Lamps, Trailer Wiring                                                                                        |
| RR PARK   | Right Rear Parking and Sidemarkers Lamps                                                                             |
| LR PARK   | Left Rear Parking and Sidemarkers Lamps                                                                              |
| PARK LP   | Parking Lamps Relay                                                                                                  |
| STARTER   | Starter Relay                                                                                                        |
| INTPARK   | Interior Lamps                                                                                                       |
| STOP LP   | Stemplamps                                                                                                           |

|            |                                                                                            |
|------------|--------------------------------------------------------------------------------------------|
| TBC BATT   | Truck Body Controller Battery Feed                                                         |
| SUNROOF    | Sunroof                                                                                    |
| SEO B2     | Off-Road Lamps                                                                             |
| 4WS        | Vent Solenoid Canister/QUADRASTEER Module Power                                            |
| RR HVAC    | Rear Climate Control                                                                       |
| AUX HVAC   | Auxiliary Power Outlet – Console                                                           |
| IGN 1      | Ignition Relay                                                                             |
| PCM 1      | Powertrain Control Module                                                                  |
| ETC/ECM    | Electronic Throttle Control, Electronic Brake Controller                                   |
| IGN E      | Instrument Panel Cluster, Air Conditioning Relay, Turn Signal/Hazard Switch, Starter Relay |
| RTD        | Ride Control                                                                               |
| TRL B/U    | Backup Lamps Trailer Wiring                                                                |
| PCM B      | Powertrain Control Module, Fuel Pump                                                       |
| F/PMP      | Fuel Pump (Relay)                                                                          |
| B/U LP     | Back-up Lamps, Automatic Transmission Shift Lock Control System                            |
| RR DEFOG   | Rear Window Defogger                                                                       |
| HDLP-HI    | Headlamp High Beam Relay                                                                   |
| PRIME      | Not Used                                                                                   |
| SIR        | Supplemental Inflatable Restraint System                                                   |
| FRT PARK   | Front Parking Lamps, Sidemarker Lamps                                                      |
| DRL        | Daytime Running Lamps (Relay)                                                              |
| SEO IGN    | Rear Defog Relay                                                                           |
| TBC IGN1   | Truck Body Controller Ignition                                                             |
| HI HDLP-LT | High Beam Headlamp-Left                                                                    |
| LH HID     | Not Used                                                                                   |
| DRL        | Daytime Running Lamps                                                                      |
| IPC/DIC    | Instrument Panel Cluster/Driver Information Center                                         |
| HVAC/ECAS  | Climate Control Controller                                                                 |
| CIG LTR    | Cigarette Lighter                                                                          |
| HI HDLP-RT | High Beam Headlamp-Right                                                                   |
| HDLP-LOW   | Headlamp Low Beam Relay                                                                    |
| A/C COMP   | Air conditioning Compressor                                                                |
| A/C COMP   | Air conditioning Compressor Relay                                                          |
| RR WPR     | Rear Wiper/Washer                                                                          |
| RADIO      | Audio System                                                                               |
| SEO B1     | Mid Bussed Electrical Center, HomeLink, Rear Heated Seats                                  |
| LO HDLP-LT | Headlamp Low Beam-Left                                                                     |
| BTSI       | Brake Transmission Shift Interlock System                                                  |
| CRANK      | Starting System                                                                            |
| LO HDLP-RT | Headlamp Low Beam-Right                                                                    |
| FOG LP     | Fog lamp Relay                                                                             |
| FOG LP     | Fog Lamp                                                                                   |
| HORN       | Horn Fuse                                                                                  |

|           |                                              |
|-----------|----------------------------------------------|
| HORN      | Horn Relay                                   |
| W/S WASH  | Windshield and Rear Window Washer Pump Relay |
| W/S WASH  | Windshield and Rear Window Washer Pump       |
| INFO      | OnStar/Rear Seat Entertainment               |
| RADIO AMP | Radio Amplifier                              |
| RH HID    | Not Used                                     |
| HORN      | Horn                                         |
| EAP       | Electric Adjustable Pedals                   |
| TREC      | All-Wheel Drive Module                       |
| SBA       | Supplemental Brake Assist                    |