


Dodge Durango 2006 fuse box diagram

Interior Fuses



Dodge Durango – fuse box – interior box

Cavity	Ampere rating [A]	Description
F1	15	Instrument Cluster Battery Feed
F2	10	Occupant Classification Module (OCM) Battery Feed
F3	10	Ignition Run/Start for Controller (NGC), Integrated Power Module (IPM), AC Relay and Fuel Pump Relay
F4	10	Door Node and Non-Memory Power Mirror Switch Battery Fuse Block Feed
F5	(2) 10	Airbags (2 Fuses in Yellow Holder)
F6	10	Ignition Run/ Start Unlock

F7	25	Radio Battery Feed
F8	10	Ignition Run/Start fro Cluster/Transfer Case/Seat Sw. Back lighting
F9	10	SDAR/DVD Battery Feed
F10	10	Spare
F11	10	Heated Mirrors
F12	20	Cluster Battery Feed
F13	10	Ignition Run HVAC Module/ Heated Rear Glass (EBL) Relay
F14	10	ABS Module Ignition Run
F15	15	Battery Feed Blue Tooth, Compass/Trip Computer (CMTC), Sentry Key Diagnostics
F16	20	Reconfigurable Power Outlets
F17	20	Cigar Lighter Ignition
F18	10	Spare Fuse
F19	15	Heating & Air Conditioning w/ATC Only Battery Feed
F20	25	Amplifier Battery Feed

Underhood Fuses (Power Distribution Center)

Cavity	Cartridge Fuse / Relay	Mini Fuse	Description
1	30		Starter
2	30		Front Wiper
3	40		Brake Batt
4	30		JB Feed Acc #2
5	40		Power Seats
6	20		JB Feed Ign #1
7	40		JB Feed Ign #2
8	40		JB Feed Acc Delay
9	Spare		
10	30		ASD
11	40		Power Liftgate (If Equipped)
12	40		JB Feed / EBL / T Case Brake
13	30		JB Feed RR
14	40		ABS Pump

15	50		JB Feed
16		10	Crank
17		Spare	
18		20	Fuel Pump
19		20	NGC
20		Spare	
21		20	ABS Batt
22		20	NGC Batt
23		20	Trailer Tow
24		15	A/C Clutch
25		15	JB Feed Stop
26		Spare	
27		10	JB Feed Acc #1
28		Spare	
29	Relay		Run Start

30	Relay		Run Remote
31	Spare		
32	Relay		Starter
33	Relay		ETAX
34	Relay		AC Clutch
35	Relay		Fuel Pump Rly
36	Spare		
37	Spare		Brake Supression
38	Spare		
39	Relay		Blower Motor
40	Relay		ASD Rly

Underhood Fuses (Integrated Power Module)

Cavity	Cartridge Fuse / Relay	Ampere rating [A]	Description
1	Relay		Wiper On/Off Rly
2	Relay		Wiper Hi/Lo Rly
3	Relay		Horn Rly

4	Relay		Rear Wiper Rly
5	Relay		Lt T-Tow Stop/Turn Rly
6	Relay		Rt T-Tow Stop/Turn Rly
7	Relay		Park Lamps Rly
8		10	Lt Park Lamps
9		10	T-Tow Park Lamps
10		10	Rt Park Lamps
11	Relay		Rad Fan Hi Rly
12		20	FCM Batt #4
13		20	FCM Batt #2
14		20	Adjustable Pedal
15		20	Ft Fog Lamps
16		20	Horn
17		20	Rear Wiper
18		20	FCM Batt #1

19		20	Lt T-Tow Stop/Turn
20		20	FCM Batt #3
21		20	Rt T-Tow Stop/Turn
22	20		FCM Batt #5
23	40		Rad Fan
24	Relay		Rad Fan Lo Rly
25	Relay		Ft Fog Lamps Rly
26	Relay		Adjustable Pedal Rly
27		30	IOD #1
28		30	IOD #2
29			Spare
30			Spare