











- * 7 : w/ Entry & Start System
- * 8 : Before Aug. 2008 Production Except Europe,
Before Dec. 2008 Production Europe
- * 9 : From Aug. 2008 Production Except Europe,
From Dec. 2008 Production Europe
- * 13 : Before Dec. 2008 Production Europe
- * 14 : From Dec. 2008 Production Europe
- * 15 : Before Feb. 2010 Production
- * 16 : From Feb. 2010 Production


A 12
Black




A 26
Black




A 27
Black




A 51
Gray




A 67
Black




A 80
Gray




B 32
Black




B127
Gray




B128
Gray




E 14
Gray




E 16
White



E 19
White



E 20
White




E 21

White




E 22

White




E 41

White




E 42


White




E 49
Yellow




E 63
White




E 67
White




E 75
Gray




E 76
Black




E 77
Gray




E 95
White




E111
Gray




E115
Gray




K 6
Black






- * 1 : Gasoline Except 3ZR-FAE
- * 2 : Diesel
- * 3 : w/ VSC
- * 4 : w/o VSC
- * 5 : Automatic A/C
- * 6 : Manual A/C
- * 8 : Before Aug. 2008 Production Except Europe,
Before Dec. 2008 Production Europe
- * 9 : From Aug. 2008 Production Except Europe,
From Dec. 2008 Production Europe
- * 12 : 3ZR-FAE
- * 13 : Before Dec. 2008 Production Diesel
- * 14 : From Dec. 2008 Production Diesel
- * 15 : Before Feb. 2010 Production
- * 16 : From Feb. 2010 Production




E19(B), E20(C)
Main Body ECU




K6(A), K25(B)
Yaw Rate Sensor



E21(B)
Power Steering ECU



E49(C)
Airbag Sensor
Assembly Center




E77(A), E115(B)
Junction
Connector




E87(A), E112(B)
Junction
Connector




E88(A), E89(B),
E113(C), E114(D)
Junction
Connector




A27
Skid Control ECU
with Actuator




E42(A)
A/C Amplifier




E41(A)
A/C Amplifier




E67
4WD Control ECU







A 12
Black




A 26
Black




A 27
Black




A 51
Gray




A 67
Black




A 80
Gray




B 32
Black




B127
Gray




B128
Gray




E 14
Gray




E 16
White



E 19
White




E 20
White




E 21

White




E 22

White




E 41

White




E 42

White




E 49

Yellow




E 63

White




E 67

White




E 77

Gray




E 87

Gray




E 88

Blue



E 89

Blue




E 95

White



E112

Gray



E113

Black

