


CRUISE CONTROL MAIN SWITCH REPLACEMENT

82040-01

HINT:

Installation is in the reverse order of removal.

1. **PRECAUTION** ([SEE PAGE 60-1](#))
2. **DISCONNECT BATTERY NEGATIVE TERMINAL** ([SEE PAGE 60-1](#))
3. **REMOVE STEERING WHEEL COVER LOWER NO.2**
4. **REMOVE STEERING WHEEL COVER LOWER NO.3**
5. **REMOVE HORN BUTTON ASSY** ([SEE PAGE 60-20](#))



6. REMOVE CRUISE CONTROL MAIN SWITCH

- (a) Disconnect the connector.
- (b) Remove the 2 screws and cruise control main switch.

7. **INSTALL HORN BUTTON ASSY** ([SEE PAGE 60-20](#))
8. **CONNECT BATTERY NEGATIVE TERMINAL** ([SEE PAGE 19-2](#))
9. **INSPECT HORN BUTTON ASSY** ([SEE PAGE 60-14](#))
10. **INSPECT SRS WARNING LIGHT** ([SEE PAGE 05-1165](#))
11. **PERFORM INITIALIZATION** ([SEE PAGE 01-29](#))