

27.Fuel Filter

A: SPECIFICATION

Fuel filter forms a single unit with fuel pump. Refer to “Fuel Pump” for removal and installation. <Ref. to FU(H6DO)-45, REMOVAL, Fuel Pump.> <Ref. to FU(H6DO)-45, INSTALLATION, Fuel Pump.>