


Suzuki Swift 1989 – 1994 fuse box diagram

Passenger Compartment Fuse Box




Suzuki Swift – fuse box diagram –

passenger compartment

Nº	A	Description components
1	10	Left Side Headlight & High Beam Indicator
2	10	Right Side Headlight
3	15	Dome Light, License Plate Light, Front & Rear Marker Light, Instrument Panel Illumination
4	15	Front Foglight
5	15	Hazard Warning Circuit & Horn
6	20	Ignition System & Gauges, Warning Lights
7	20	Heater Fan Motor, A/C Circuit
8	15	Stoplights

9	15	Cigarette Lighter & Radio
10	10	Back-Up Light
11	15	Rear Defogger
12	15	Front & Rear Wiper/Washer
Relay		
13	Switch	
14	Turn Signal	

Engine Compartment Fuse Box



Suzuki Swift – fuse box diagram – engine

compartment

Nº	A	Description components
A	60	Main
B	40	Primary

C	30	Primary
D	30	A/C
E	15	Electronic Fuel Injection
F	15	A/C