





- A 1 Front Clearance Light LH (Headlight Assembly LH)
- A 2 Front Turn Signal Light LH (Headlight Assembly LH)
- A 3 Headlight Leveling Motor LH
- A 4 Front Speed Sensor LH
- A 5 Front Airbag Sensor LH
- A 6 Fog Light Assembly LH
- A 7 Headlight Assembly LH
- A 8 Front Clearance Light RH (Headlight Assembly RH)
- A 9 Front Turn Signal Light RH (Headlight Assembly RH)
- A 10 Headlight Leveling Motor RH
- A 11 Front Speed Sensor RH
- A 12 Front Airbag Sensor RH
- A 13 Fog Light Assembly RH
- A 14 Headlight Assembly RH
- A 16 Skid Control ECU with Actuator Assembly
- A 19 ECM
- A 20 Windshield Wiper Motor Assembly
- A 21 Windshield Washer Motor and Pump Assembly
- A 22 Rear Washer Motor & Pump Assembly
- A 23 Low Pitched Horn Assembly
- A 24 Brake Fluid Level Warning Switch (Brake Master Cylinder Reservoir Assembly)
- A 25 Cooler Thermistor (Ambient Temperature Sensor)
- A 26 A/C Pressure Sensor (Air Conditioning Tube Assembly)
- A 28 Wireless Door Lock Buzzer
- A 32 Cooling Fan Motor
- A 34 Diesel Turbo Pressure Sensor
- A 35 Level Warning Switch
- A 36 Fuel Heater Assembly
- A 37 Intake Mass Air Flow Meter Assembly
- A 38 No. 2 Exhaust Gas Temperature Sensor
- A 39 Differential Pressure Sensor Assembly
- A 42 Heater Pump Assembly
- A 45 Heater Assembly
- A 46 Cooling Fan Resistor
- A 47 Intake Air Temperature Sensor
- A 51 Fusible Link Block Assembly
- A 52 Fusible Link Block Assembly

Position of Parts in Engine Compartment <LHD 1ND-TV>


A 1

Black



A 2

Gray




A 3

Black




A 4

Black




A 5

Yellow



A 6

Black




A 7

Gray



A 8

Black



A 9

Gray




A 10

Black



A 11

Black




A 12

Yellow



A 13

Black




A 14

Gray




A 16

Black



A 19

Black



A 20

White



Position of Parts in Engine Compartment <LHD 1ND-TV>

