




- D 1 Combination Meter Assembly
- D 2 Combination Meter Assembly
- D 3 Turn Signal Flasher Assembly
- D 4 Hazard Warning Signal Switch Assembly
- D 5 Instrument Cluster Finish Panel Assembly
- D 6 No. 2 Heater Control Sub-Assembly
- D 7 No. 1 Heater Control Sub-Assembly
- D 8 No. 3 Heater Control Sub-Assembly
- D 9 Heater Switch Assembly
- D 10 No. 1 Cooler Thermistor
- D 11 Cooler Thermistor (Room Temperature Sensor)
- D 12 Blower with Fan Motor Sub-Assembly
- D 13 Blower Resistor
- D 14 Blower with Fan Motor Sub-Assembly
- D 15 A/C Amplifier Assembly
- D 16 A/C Amplifier Assembly
- D 17 A/C Amplifier Assembly
- D 18 Un-Lock Warning Switch Assembly
- D 19 Spiral Cable Sub-Assembly
- D 20 Steering Sensor

Position of Parts in Instrument Panel <LHD>

