

## Mercury Sable 1995 – 1996 fuse box diagram

Fuse box in instrument panel



Mercury Sable 3rd Generation – fuse box – instrument panel

| Fuse/relay | Ampere rating [A] | Description |
|------------|-------------------|-------------|
| 1          | —                 | Not used    |

|    |    |                                                           |
|----|----|-----------------------------------------------------------|
| 2  | 5  | Instrument illumination                                   |
| 3  | 10 | Left low beam headlamp                                    |
| 4  | 10 | Right low beam headlamp                                   |
| 5  | 5  | Brake shift interlock, rear defroster                     |
| 6  | 15 | MLPS switch, backup lamps, speed control, climate control |
| 7  | 10 | MLPS switch, starter relay                                |
| 8  | 5  | Power antenna, RCU, GEM                                   |
| 9  | 10 | ABS, central temperature monitor                          |
| 10 | 20 | EEC relay, ignition coil, PATS, Radio                     |


|    |    |                                                                      |
|----|----|----------------------------------------------------------------------|
| 11 | 5  | Air bag, instrument cluster                                          |
| 12 | 5  | Instrument cluster, autolamps, transmission control switch, ICP, GEM |
| 13 | 5  | Air bag, blower motor, EATC                                          |
| 14 | 5  | Air suspension, LOM                                                  |
| 15 | 10 | Multi-function switch (turn signal)                                  |
| 16 | —  | Not used                                                             |
| 17 | 30 | Front wiper/washer                                                   |
| 18 | 5  | Headlamp switch                                                      |
| 19 | 15 | Rear wiper/washer                                                    |

|    |    |                                                |
|----|----|------------------------------------------------|
| 20 | 5  | ICP, remote entry, cellular phone              |
| 21 | 20 | Cigar lighter                                  |
| 22 | 5  | Power mirrors, antenna, decklid lamp, autolamp |
| 23 | 5  | GEM, PATS, RAP                                 |
| 24 | 5  | ICP, RCC, Speedometer                          |
| 25 | 10 | Data link connector                            |
| 26 | 15 | Trunklid                                       |
| 27 | 10 | Battery saver relay                            |
| 28 | 15 | Speed control, stop lamps                      |

|          |    |                                                       |
|----------|----|-------------------------------------------------------|
| 29       | 15 | Multi-function switch, hazard                         |
| 30       | 15 | High beams, daytime running lamps, instrument cluster |
| 31       | 5  | Tail lamp feed                                        |
| 32       | 5  | ICP, heated mirrors                                   |
| 33       | 5  | Power windows, lock illumination                      |
| RELAY 34 | —  | Battery saver relay                                   |
| RELAY 35 | —  | Driver's unlock relay                                 |
| RELAY 36 | —  | Rear defrost relay                                    |
| RELAY 37 | —  | Interior lamp relay                                   |

|          |   |                             |
|----------|---|-----------------------------|
| RELAY 38 | — | One touch window down relay |
| RELAY 39 | — | Accessory delay relay       |

#### Power distribution box



Mercury Sable 3rd Generation – fuse box – power distribution box

| Fuse/Relay | Ampere rating [A] | Description    |
|------------|-------------------|----------------|
| 1          | 40                | Junction block |

|    |    |                     |
|----|----|---------------------|
| 2  | 30 | EEC power           |
| 3  | 40 | Ignition            |
| 4  | 30 | Power locks         |
| 5  | 40 | Ignition            |
| 6  | 30 | Power seats         |
| 7  | 4  | Rear window defrost |
| 8  | 30 | Thermactor pump     |
| 9  | 40 | Cooling fan         |
| 10 | 20 | Fuel pump           |

|    |    |                        |
|----|----|------------------------|
| 11 | 40 | Blower motor           |
| 12 | 20 | Semi-active suspension |
| 13 | 40 | ABS module             |
| 14 | 20 | Radio                  |
| 15 | 15 | Datime running lamps   |
| 16 | 10 | Air bag                |
| 17 | 20 | Radio                  |
| 18 | 30 | Headlamps              |
| 19 | 15 | Horn                   |

|          |    |                    |
|----------|----|--------------------|
| 20       | 15 | Park lamps         |
| 21       | —  | Not used           |
| 22       | 30 | Headlamps          |
| RELAY 23 | —  | Blower motor relay |
| RELAY 24 | —  | Wiper park relay   |
| RELAY 58 | —  | Wiper hi/lo relay  |
| 26       | 30 | Alternator         |
| 27       | 10 | Hego power         |
| RELAY 28 | —  | Washer motor relay |

|          |   |                         |
|----------|---|-------------------------|
| RELAY 29 | — | Horn relay              |
| RELAY 30 | — | Autolamp headlamp relay |
| RELAY 31 | — | Starter relay           |
| RELAY 32 | — | Autolamp park relay     |