


2. PARKING BRAKE LEVER AND CABLE



PB-00131

- | | |
|--------------------------------------|----------------------------|
| (1) Parking brake lever | (5) Bracket |
| (2) Parking brake switch | (6) Clamp |
| (3) Adjusting nut (Self-locking nut) | (7) Parking brake cable RH |
| (4) Equalizer | (8) Clamp |

- (9) Parking brake cable LH

Tightening torque: N·m (kgf-m, ft-lb)

T: 18 (1.8, 13)

C: CAUTION

- Wear appropriate work clothing, including a cap, protective goggles and protective shoes when performing any work.
- Before removal, installation or disassembly, be sure to clarify the failure. Avoid unnecessary removal, installation, disassembly and replacement.
- Vehicle components are extremely hot after driving. Be wary of receiving burns from heated parts.
- Use SUBARU genuine grease etc. or equivalent. Do not mix grease etc. of different grades or manufacturers.
- Be sure to tighten fasteners including bolts and nuts to the specified torque.
- Place shop jacks or rigid racks at the specified points.
- Make sure grease does not come into contact with the parking shoes.