


Vauxhall Vivaro 2001 – 2014 fuse box diagram

The Instrument Panel Fuse Panel



Vauxhall Vivaro – fuse box diagram – instrument panel


Number	Description
1	—
2	Radio
3	—
4	—
5	—
6	—
7	AC, rear

8	—
9	Fog lamps
10	Central locking
11	Interior illumination
12	Diagnostic plug, immobiliser
13	Rear screen heating
14	Rear screen wiper/washer system
15	Screen wipers
16	Brake light
17	ABS
18	—
19	Window winders
20	Window winders
21	Seat heating
22	—

23	—
24	Radio
25	Heating
26	Accessories
27	High beam, left
28	High beam, right
29	Low beam, left
30	Low beam, right
31	Tail lamp, left
32	Tail lamp, right
33	Rear fog lamp
34	Horn
35	Mirror heating
36	Windscreen heating control
37	—

38	—
39	—

Relay Box



Vauxhall Vivaro – fuse box diagram – relay box

Number	Relay
A	Relay for the rear screen heating
B	Time-out for rear screen wipers
C	Relay for the rear screen wipers
D	Relay + after-contact
E	AC tripping relay
F	Relay for the heatable windscreen

G	Relay for the fog lamps
H	“Headlight” relay for low beam
I	“Headlight” relay for parking lights
J	“Headlight” main relay
K	Relay for the electronic thermostat

The relay for the electronic thermostat is installed on the left-hand side of the air mixer and distributor.

Fuse Box in The Engine Compartment



. Vauxhall Vivaro – fuse box diagram –

engine compartment

Number	A	Relay
14	—	—
15	—	—

16	40	AC
17	50	Windscreen heating
18	50	Windscreen heating
19	60	PDB
20	60	ABS
21	60	PDB
22	60	PDB
23	50	Radiator fan
	60	
	70	
24	50	Warning autofuse
	60	
25	70	Pre-heating
Relay		
1	Auxiliary heater: 2 or 3 add-on heater Diesel: Parking heater relay	

2	Diesel: Relay for fuel injection computer Petrol: Injection interrupt
3	Diesel pump relay
4	Fuel pump/diesel pre-heating relay
5	Diesel parking heater: Relay for fan unit, second speed level
6	Coupling relay: AC compressor
7	1 add-on heater (thermo-plunger) relay
8	2 or 3 add-on heater (thermo-plungers) Petrol: Parking heater relay
9	Diesel: Fan unit Diesel: Relay for second speed level with AC Petrol: First speed level with AC
10	Petrol: Fan unit Diesel: Relay for first speed level of the fan with AC Petrol: Second speed level with AC
11	—
12	Relay for heatable windscreen.
13	Relay for heatable windscreen.

In the diesel version the vehicle is either equipped with an auxiliary heater or with a parking heater.

