


Mercury Mystique 1995 – 1996 fuse box diagrams

Power distribution box



Mercury Mystique – fuse box – power distribution

Fuse	Ampere rating [A]	Description
1	80	Main power supply

2	60	Engine cooling fan
3	60	ABS braking system
4	20	Daytime running lights (Canada), ignition
5	15	Fog light
6	—	Not used
7	30	ABS braking system
8	30	Air pump
9	20	EEC module
10	20	Ignition module


11	3	EEC module
12	15	Hazard flasher, horn
13	15	HEGO sensor
14	15	Fuel pump
15	10	Right low beam
16	10	Left low beam
17	10	Right high beam
18	10	Left high beam

Relay	Relay Color	Description
-------	-------------	-------------

R1	white	Daytime running lights (Canada)
R2	black	High speed engine cooling fan
R3	blue	A/C wide open throttle
R4	yellow	A/C clutch relay
R5	dark green	Engine cooling fan
R6	yellow	Starter
R7	brown	Horn
R8	brown	Fuel pump
R9	white	Low beam

R10	white	High beam
R11	brown	PCM module
D1	black	Reverse voltage protection

Instrument panel fuses



Mercury Mystique – fuse box – instrument panel

Fuse	Ampere rating [A]	Description
------	-------------------	-------------

19	7,5	Heated rear view mirrors
20	10 CB	Wipers
21	40	Power windows
22	7,5	ABS module
23	15	Backup lamps
24	15	Brakelamps
25	20	Door locks
26	7,5	Main light
27	15	Cigar lighter

28	30	Power seats
29	30	Rear window defrost
30	7,5	Engine management system
31	7,5	Instrument panel illumination
32	7,5	Radio
33	7,5	Left hand parking lamps
34	7,5	Courtesy lamps
35	7,5	Right-hand parking lamps
36	10	Air bag

37	30	Blower motor
38	—	Not used

Relay	Relay color	Description
R12	White	Courtesy lights
R13	Yellow	Rear window defroster
R14	Yellow	Heater fan motor
R15	Green	Wipers
R16	Black	Ignition
D2	Black	Reverse voltage protection

R17	—	Not used
R18	Black	Express down windows
R19	Blue	Speed control cut-out
R20	—	Not used
R21	—	Not used
R22	White	Fog lamps
R23	Black	Turn signal
R24	White	Left panic alarm flasher
F25	White	Right panic alarm flasher

F26	—	Not used
F27	—	Not used
R28	—	Not used
R29	Brown	Door lock control