

Vauxhall Movano B 2016 fuse box diagram

Engine compartment fuse box

Located below the coolant expansion tank. Some circuits may be protected by several fuses


Symbol	Circuit
	Right side lights
	Left side lights
	Right low beam
	Left low beam
	Front fog light
	Left high beam
	Right high beam

	ABS
	Windscreen wiper
	Heating and ventilation system / Air conditioning
	Heated windscreen

Instrument panel fuse box

Located behind the trim panel on the left-hand side of the instrument panel. Pull upper part of trim panel to remove. Do not store any objects behind this panel.

Some circuits may be protected by several fuses.

Symbol	Circuit
	Infotainment system / Seat heating / Vehicle display screen / Audio connections / Alarm
	Power outlet
	Cigarette lighter
	Instrument panel

	Central locking
	Interior lights
	Turn signals / Rear fog lights / Body control module
	Diagnostic connector
	ABS / Electronic Stability Program
	Interior lights / Brake lights
	Body control module
	Brake light
	Body control module / Power windows / Heating and ventilation system / Air conditioning
	Left heated rear window
	Right heated rear window

	Windscreen washer
	Electronic immobiliser
	Heated seats
FBL	Cornering light
	Hands-free connection
T	Tachograph
PTO	Power take-off
	Horn
	Preheating / Diesel fuel filter
	Climate control fan
	Heated exterior mirrors

	Left-hand side light
	Right-hand side light
	Pneumatic suspension
	Navigation system
ADP	Additional adaptations
	Power windows / Body control module