


Chevrolet S-10 1993 – 1994 fuse box diagram

Instrument panel

The fuse block is in the instrument panel on the driver's side.



Chevrolet S-10 – fuse box –

instrument panel

Fuses/Circuit Breaker	Name	Circuit protected
A	PWR ACCY	Power Door Locks
B	PWR WDO	Power Window
1	STOP/HAZ S	Stop Lamps, Hazard Lamps, Chime Module
2	HORN/DM	Dome Lamp, Lighted Visor Mirror, Glove Box Lamp, Horn, I/P Courtesy Lamps, Power Mirror
3	T/L CTSY	Electric Shift Transfer Case Module, Park Lamps, License Plate Lamp
4	GAUGES	Auto Transmission, Alternator Field, Variable Throttle Control, A/C Compressor, Cluster, Chime Module, Four-wheel Drive Indicator Lamp, Heated Oxygen Sensor, Daytime Running Lamps Module
5	(NOT USED)	—
6	HTR A/C	Blower Motor, Temperature Door Motor
7	PWR AUX	Pwr Auxiliary Outlets
8	(NOT USED)	—
9	ECM BATT	Engine Computer (Battery), ABS Battery, Fuel Pump
10	ECM IGN	Engine Computer (Ignition), Injectors, Engine Sensors
11	RADIO	Radio, Inside Rearview Mirror Map Lamps

12	(NOT USED)	—
13	RDO/BATT	Clock, Radio Battery, CD Player
14	ILLUM	Cluster Illumination, Ash Tray Lamp, Radio Illumination, Heater Lamp, Four-wheel Drive Illumination, Chime Module, Fog Lamp Switch Illumination, Daytime Running Lamps
15	DRL	Daytime Running Lamps (Canada Only)
16	TURN B/U	Turn Signals, Backup Lamp
17	WIPER	Windshield Washer, Windshield Wiper Motor
18	BRAKE	Speedometer, Anti-lock Braking System, Cruise Control
19	4WD	Four-wheel Drive
20	(NOT USED)	—
21	FOG	Fog Lamps
22	(NOT USED)	—
23	(NOT USED)	—
24	(NOT USED)	—