

Vauxhall Zafira B 2005 – 2015 fuse box diagram

Engine compartment fuse box



Vauxhall Zafira B – fuse box – engine compartment

Insert a screwdriver into the opening as far as it will go and tilt it sideways. Open the cover upwards and remove.

The fuse box has two different fuse assignments depending on the load compartment fuse box variant,

Fuse assignments in conjunction with load compartment fuse box version A

Number	Circuit	Rating
1	ABS	20
2	ABS	30
3	Interior fan, Electronic Climate Control (ECC)	40
4	Interior fan heating and air conditioning system	40

5	Cooling fan 1 (dep ending on engine)	30
		40
6	Cooling fan 2 (dep ending on engine)	20
		30
7	Central locking system	20
8	Windscreen washer, rear window washer	10
9	Heated rear window, heated exterior mirror	30
10	Diagnostics plug	7,5
11	Instruments	7,5
12	Mobile telephone, digital radio, Twin Audio, display	7,5
13	Courtesy light	5
14	Windscreen wiper	30
15	Windscreen wiper	30
16	Horn, ABS, brake light switch, air conditioning system	5
17	Diesel fuel filter or air conditioning system	25

		20
18	Starter	25
19	—	—
20	Horn	15
21	Engine electronics	20
22	Engine electronics	7,5
23	Headlight range adjustment	5
24	Fuel pump	15
25	—	—
26	Engine electronics	10
27	Heating, air conditioning system, air quality sensor	7,5
28	—	—
29	Electro-hydraulic power-assisted steering	5
30	Engine electronics	10
31	Rear window wiper	15

32	Brake light switch	5
33	Headlight range adjustment, light switch, clutch switch, instrument, driver's door module	5
34	Control unit, steering column module	7,5
35	Infotainment system	20
36	Cigarette lighter, front power outlet	15

Fuse assignments in conjunction with load compartment fuse box version B

Number	Circuit	Rating
1	ABS	20
2	ABS	30
3	Interior fan, Electronic Climate Control (ECC)	40
4	Interior fan heating and air conditioning system	40
5	Cooling fan 1 (depending on engine)	30
		40
6	Cooling fan 2 (depending on engine)	20
		30

		40
7	Windscreen washer system	10
8	Horn	15
9	Headlight washer system	25
10	Emergency unlocking of central locking system	20
11	—	—
12	—	—
13	Front fog lights	15
14	Windscreen wiper	30
15	Windscreen wiper	30
16	Control module electronics, Open&Start system, ABS, brake light switch	5
17	Diesel fuel filter heating	25
18	Starter	25
19	Transmission electronics	30
20	Air conditioning system	10

21	Engine electronics	20
22	Engine electronics	7,5
23	Adaptive forward lighting, headlight range adjustment	10
24	Fuel pump	15
25	Transmission electronics	15
26	Engine electronics	10
27	Electro-hydra ulic power-assisted steering	5
28	Transmission electronics	5
29	Transmission electronics	7,5
30	Engine electronics	10
31	Adaptive forward fighting, headlight range adjustment	10
32	Brake system, air conditioning system, clutch switch	5
33	Adaptive forward lighting, headlight range adjustment, light switch	5
34	Steering column control unit	7,5
35	Infotainment system	20

36	Mobile telephone, Infotainment system, display	7,5
----	--	-----

Load compartment fuse box

The fuse box is behind a cover. Press the locking tabs forward and remove the cover.

Do not store any objects behind the cover.

Depending on the equipment, there are two different fuse boxes.

Fuse box version A



Vauxhall Zafira B – fuse box – load


compartment – version A

To replace a fuse, remove the relevant protective cap.

Number	Circuit	Rating
1	Fog light	15
2	Rear power outlet	15
3	Load compartment power outlet	15
4	Reversing lights	7,5
5	Rear power windows	30

6	Air conditioning system	10
7	Front power windows	30
8	Heated exterior mirrors	7,5

Fuse box version B



Vauxhall Zafira B – fuse box – load compartment version

B

Number	Circuit	Rating
1	Electric windows, front	25
2	—	—
3	Instruments	7,5
4	Heating, air c onditioning system, Electronic Climate Control (ECC)	5
5	Airbags	7,5

6	—	—
7	—	—
8	—	—
9	—	—
10	—	—
11	Heated rear window	25
12	Rear window wiper	15
13	Parking distance sensors	5
14	Heating, air conditioning system	7,5
15	—	—
16	Seat occupancy recognition, Open&Start system	5
17	Rain sensor, air quality sensor, Tyre Pressure Monitoring System , interior mirror	5
18	Instruments, switches	5
19	—	—
20	CDC	10

21	Heated exterior mirrors	7,5
22	—	—
23	Electric windows, rear	25
24	Diagnostics plug	7,5
25	—	—
26	Electrically retractable exterior mirrors	7,5
27	Ultrasonic sensor, Vauxhall alarm system	5
28	—	—
29	Cigarette lighter, front power outlet	15
30	Rear power outlet	15
31	—	—
32	—	—
33	Open&Start system	15
34	—	—
35	Rear power outlet	15

36	Socket for towing equipment	20
37	—	—
38	Central locking system, terminal 30	25
39	Seat heater (left)	15
40	Seat heater (right	15
41	—	—
42	—	—
43	—	—
44	—	—